

```

00001          NAM    UPROM
00002          *
00003          IFP1
00005          ENDC
00006          *
00007  0000  87CD19AF          MOD    MODEND,MODNAM,PRGRM+OBJECT,REENT+1,MODENT,
00008          *
00009  000D  5550524F  MODNAM  FCS    "UPROM"
00010          *
00011          TTL     UPROM OS-9 EQUATES
00012          *
00013          *****
00014          *          UNIVERSAL EPROM PROGRAMMER SOFTWARE, VERSION 2.05          *
00015          *****
00016          *
00017          *          WINDRUSH MICRO SYSTEMS LIMITED, WORSTEAD LABORATORIES          *
00018          *          NORTH WALSHAM, NORFOLK, ENGLAND      TEL: (0692) 405189          *
00019          *
00020          *****
00021          *
00022          *          THIS VERSION HAS BEEN CUSTOMISED FOR OS-9, LEVEL ONE.          *
00023          *
00024          *          THIS VERSION WILL NOT RUN ON LEVEL TWO DUE TO THE          *
00025          *          MEMORY MANAGEMENT/PROTECTION SCHEME USED BY MICROWARE.          *
00026          *
00027          *          A VERSION FOR LEVEL TWO IS IN DEVELOPMENT AND SHOULD BE          *
00028          *          AVAILABLE IN THE THIRD QUARTER OF 1982.          *
00029          *
00030          *****
00031          *
00032          *  BUFFLO AND BUFFHI EQUATES          * NOT USER MODIFIABLE *          *
00033          *
00034          *****
00035          *
00036  0000          BUFFLO  EQU    $0000          EPROM DATA BUFFER LOW LIMIT
00037  4000          BUFFHI  EQU    $4000          EPROM DATA BUFFER HIGH LIMIT+1
00038          *
00039          *****
00040          *
00041          *  USER MODIFIABLE EQUATES          *
00042          *
00043          *****
00044          *
00045  FFFF          PWRDLY  EQU    $FFFF          POWER-UP DELAY FOR A 2MHZ SYST
00046          *PWRDLY EQU $7FFF POWER-UP DELAY FOR A 1MHZ SYSTEM
00047          *
00048  0008          DCYCLA  EQU    $0008          TRI-VOLT EPROMS REST TIME (30
00049  0008          DCYCLB  EQU    $0008          5.0 VOLT EPROMS REST TIME (30
00050          *
00051          *****
00052          *
00053          *  RAM SCRATCH PAD          *
00054          *
00055          *****
00056          *
00057  D 0000          ORG     0
00058          *
00059  D 0000          START  RMB    2          MSB OF EPROM START ADDR
00060  D 0002          FINISH RMB    2          MSB OF EPROM END ADDRESS
00061  D 0004          ADDRH  RMB    1          MSB OF EPROM RUNNING ADDRESS

```

00062	D	0005	ADDRL	RMB	1	LSB OF SAME
00063	D	0006	CIMAGE	RMB	2	IMAGE OF CONTROL LATCH DATA
00064	D	0008	SAVEX	RMB	2	X REG SAVE
00065	D	000A	LIMIT	RMB	2	LIMIT FOR LIMCHK ROUTINE
00066	D	000C	BUFEND	RMB	2	END OF BUFFER POINTER
00067	D	000E	TYPE	RMB	1	EPROM TYPE FLAG
00068	D	000F	SAVEXA	RMB	2	
00069	D	0011	SAVEXB	RMB	2	X REG SAVE FOR MOVE
00070	D	0013	SAVEXC	RMB	2	16 BIT COUNTER
00071	D	0015	COUNT	RMB	2	PASS COUNTER FOR TRI-VOLT EPROM
00072	D	0017	FGTRIV	RMB	1	
00073	D	0018	DCOUNT	RMB	2	DELAY MULTIPL.
00074	D	001A	STLINE	RMB	2	LINE START FOR ASCII DMP.
00075	D	001C	CKSM	RMB	1	
00076	D	001D	ERFLG	RMB	1	NON HEX CHAR FLAG
00077	D	001E	FILCAR	RMB	1	
00078	D	001F	XHI	RMB	1	MEM CHANGE BUFFER
00079	D	0020	XLOW	RMB	1	
00080	D	0021	EPRTYP	RMB	2	ADDR. OF EPROM TYPE PROMPT
00081	D	0023	XSTORE	RMB	2	TEMP STORE LOCATION
00082	D	0025	PORT	RMB	2	EPROM PROGRAMMER PIA BASE ADDR
00083	D	0027	FILE	RMB	1	AUXILIARY FILE PATH NUMBER
00084		*				
00085	D	0028		RMB	350	
00086	D	0186	STACKB	EQU	.	
00087		*				
00088		0050	NBUFFL	EQU	80	
00089	D	0186	NBUFF	RMB	NBUFFL	FILE NAME BUFFER
00090		*				
00091		4000	BSIZE	EQU	BUFFHI-BUFFLO	
00092	D	01D6	BUFFER	RMB	BSIZE	RAM BUFFER
00093	D	41D6	BUFFEND	EQU	.	
00094		*				
00095	D	41D6	MODMEM	EQU	.	
00096		*				
00097		*****				
00098		*				
00099		* START OF PROGRAM *				
00100		*				
00101		*****				
00102		*				
00103	0012		MODENT	EQU	*	
00104		*				
00105			USE		UPRM1D	
00106						
00107	0012		L			
00108						
00109			TTL		EPROM PROGRAMMER PART ONE	
00110		*				
00111	0012	32C90186	LEAS	STACKB,U		LOAD INITIAL STACK POINTER
00112		*				
00113						
00114		*****				
00115		*				
00116		* INITIALISE VARIABLES *				
00117		*				
00118		*****				
00119		*				
00120	0016	0F27	CLR		FILE	
00121		*				

```

00122      *****
00123      *
00124      * COPY PARAMETER AREA (IF ANY) INTO BUFFER *
00125      *
00126      *****
00127      *
00128      0018 10830000      CMPD  #0
00129      001C 2716         BEQ   NOINITD
00130      001E 10834000      CMPD  #BSIZE
00131      0022 2210         BHI   NOINITD
00132      0024 3420         PSHS  Y
00133      0026 31C901D6      LEAY  BUFFER,U
00134      002A A680          COPYBL LDA  ,X+
00135      002C A7A0          STA   ,Y+
00136      002E ACE4          CMPX  ,S
00137      0030 26F8          BNE   COPYBL
00138      0032 3262          LEAS  2,S
00139      0034          NOINITD EQU  *
00140      *
00141      *****
00142      *
00143      * SET PROCESS PRIORITY VERY HIGH *
00144      *
00145      *****
00146      *
00147      0034 103F0C          OS9   F#ID
00148      0037 1025027F        LBCS  SYSERR
00149      003B C664           LDB   #100      TRY THIS FOR MULTI-USER
00150      *LDB #254 HIGHEST PRIORITY - 1 (FOR SINGLE USER)
00151      003D 103F0D          OS9   F$SPRI
00152      0040 10250276        LBCS  SYSERR
00153      *
00154      *****
00155      *
00156      * START TALKING TO THE OPERATOR *
00157      *
00158      *****
00159      *
00160      0044 308D0DAD        LEAX  BANNER,PCR GET BANNER
00161      0048 1708A0         LBSR  PDATA2      DISPLAY IT
00162      *
00163      004B 308D0E90        PORTQ LEAX  BADDR,PCR
00164      004F 170899         LBSR  PDATA2
00165      0052 1707F9         LBSR  BADDR
00166      0055 0D1D          TST   ERFLG
00167      0057 26F2          BNE   PORTQ
00168      0059 9F25          STX   PORT
00169      *
00170      005B 8D07           BSR   INIT0
00171      005D 8D2D           BSR   INIT3      SET UP PIA'S
00172      005F 1704F6         LBSR  STOP      CLR LATCH
00173      0062 2052          BRA   QMENU
00174      *
00175      0064 9E25          INIT0 LDX   PORT      GET PORT
00176      0066 6F84          CLR   0,X      START WITH DATA REG = 0
00177      0068 A601          LDA   1,X      SET UP PIA'S
00178      006A 84FB          ANDA  #$FB
00179      006C A701          STA   1,X
00180      006E 86FF          LDA   #$FF
00181      0070 A784          STA   0,X      SET 'A' SIDE TO ALL O/P'S
  
```

00182	0072	863C		LDA	##3C	
00183	0074	A701		STA	1,X	SET 'A' SIDE DATA REG AND CA2
00184	0076	39		RTS		RETURN
00185		*				
00186	0077	9F23	INIT1	STX	XSTORE	SAVE X
00187	0079	9E25		LDX	PORT	GET PORT ADDRESS
00188	007B	6F84		CLR	0,X	
00189	007D	A603		LDA	3,X	
00190	007F	84FB		ANDA	##FB	SET DR
00191	0081	A703		STA	3,X	
00192	0083	6F02		CLR	2,X	SET TO ALL I/P
00193	0085	8A04		ORA	##04	RESTORE CR
00194	0087	A703		STA	3,X	
00195	0089	9E23		LDX	XSTORE	RESTORE X
00196	008B	39		RTS		
00197		*				
00198	008C	9F23	INIT3	STX	XSTORE	SAVE X
00199	008E	9E25		LDX	PORT	GET PORT ADDRESS
00200	0090	6F84		CLR	0,X	
00201	0092	A603		LDA	3,X	
00202	0094	84FB		ANDA	##FB	
00203	0096	A703		STA	3,X	
00204	0098	6F02		CLR	2,X	
00205	009A	863C		LDA	##3C	
00206	009C	A703		STA	3,X	SET 'B' SIDE TO DATA REG AND C
00207	009E	9E23		LDX	XSTORE	RESTORE X
00208	00A0	39		RTS		RETURN
00209		*				
00210	00A1	9F23	INIT2	STX	XSTORE	SAVE X
00211	00A3	9E25		LDX	PORT	GET PORT ADDRESS
00212	00A5	E603		LDB	3,X	GET B/SIDE C/REG
00213	00A7	C4FB		ANDB	##FB	SET DDR
00214	00A9	E703		STB	3,X	
00215	00AB	86FF		LDA	##FF	SET DDR TO ALL O/P'S
00216	00AD	A702		STA	2,X	
00217	00AF	CA04		ORB	##04	SET DATA REG
00218	00B1	E703		STB	3,X	
00219	00B3	9E23		LDX	XSTORE	RESTORE X
00220	00B5	39		RTS		RETURN
00221		*				
00222		*****				
00223		*				
00224		* ASK OPERATOR FOR EPROM TYPE *				
00225		*				
00226		*****				
00227		*				
00228	00B6	8E4000	QMENU	LDX	##UFFHI	SET LIMIT
00229	00B9	9F0A		STX	LIMIT	
00230	00BB	0F17		CLR	FGTRIV	CLR TRI-VOLT EPROM FLAG
00231	00BD	308D0E4E		LEAX	MENU,PCR	
00232	00C1	170827		LBSR	PDATA2	DISPLAY MENU
00233	00C4	17082B		LBSR	INCH	GET REPLY
00234	00C7	8130		CMPA	##30	
00235	00C9	272A		BEQ	SWMES0	
00236	00CB	8131		CMPA	##31	
00237	00CD	2736		BEQ	SWMES1	
00238	00CF	8132		CMPA	##32	
00239	00D1	2742		BEQ	SWMES2	
00240	00D3	8133		CMPA	##33	
00241	00D5	274E		BEQ	SWMES3	

00242	00D7	8134		CMPA	##34	
00243	00D9	275A		BEQ	SWMES4	
00244	00DB	8135		CMPA	##35	
00245	00DD	2766		BEQ	SWMES5	
00246	00DF	8136		CMPA	##36	
00247	00E1	2771		BEQ	SWMES6	
00248	00E3	8137		CMPA	##37	
00249	00E5	277C		BEQ	SWMES7	
00250	00E7	8138		CMPA	##38	
00251	00E9	10270085		LBEQ	SWMES8	
00252	00ED	8139		CMPA	##39	
00253	00EF	1027008E		LBEQ	SWMES9	
00254	00F3	20C1		BRA	QMENU	GO ROUND AGAIN IF ILLEGAL
00255		*				
00256	00F5	308D1071	SWMES0	LEAX	INMSG0,PCR	2508
00257	00F9	1707EF		LBSR	PDATA2	
00258	00FC	308D15E5		LEAX	H2508,PCR	
00259	0100	9F21		STX	EPRTYP	
00260	0102	16008B		LBRA	P2508	
00261		*				
00262	0105	308D10B3	SWMES1	LEAX	INMSG1,PCR	2708
00263	0109	1707DF		LBSR	PDATA2	
00264	010C	308D15E7		LEAX	H2708,PCR	
00265	0110	9F21		STX	EPRTYP	
00266	0112	160080		LBRA	P2708	
00267		*				
00268	0115	308D10ED	SWMES2	LEAX	INMSG2,PCR	2516
00269	0119	1707CF		LBSR	PDATA2	
00270	011C	308D15E9		LEAX	H2516,PCR	
00271	0120	9F21		STX	EPRTYP	
00272	0122	16008B		LBRA	P2516	
00273		*				
00274	0125	308D112F	SWMES3	LEAX	INMSG3,PCR	2716
00275	0129	1707BF		LBSR	PDATA2	
00276	012C	308D15EB		LEAX	H2716,PCR	
00277	0130	9F21		STX	EPRTYP	
00278	0132	16008B		LBRA	P2716	
00279		*				
00280	0135	308D1190	SWMES4	LEAX	INMSG4,PCR	2532
00281	0139	1707AF		LBSR	PDATA2	
00282	013C	308D15ED		LEAX	H2532,PCR	
00283	0140	9F21		STX	EPRTYP	
00284	0142	160080		LBRA	P2732	
00285		*				
00286	0145	308D11D2	SWMES5	LEAX	INMSG5,PCR	2732
00287	0149	17079F		LBSR	PDATA2	
00288	014C	308D15EF		LEAX	H2732,PCR	
00289	0150	9F21		STX	EPRTYP	
00290	0152	2071		BRA	P2732	
00291		*				
00292	0154	308D1205	SWMES6	LEAX	INMSG6,PCR	2732A
00293	0158	170790		LBSR	PDATA2	
00294	015B	308D15F2		LEAX	H2732A,PCR	
00295	015F	9F21		STX	EPRTYP	
00296	0161	2062		BRA	P2732	
00297		*				
00298	0163	308D1243	SWMES7	LEAX	INMSG7,PCR	2564
00299	0167	170781		LBSR	PDATA2	
00300	016A	308D15F5		LEAX	H2564,PCR	
00301	016E	9F21		STX	EPRTYP	

00302	0170 2063		BRA	P2764	
00303	*				
00304	0172 308D127E	SWMES8	LEAX	INMSG8,PCR	2764
00305	0176 170772		LBSR	PDATA2	
00306	0179 308D15F8		LEAX	H2764,PCR	
00307	017D 9F21		STX	EPRTYP	
00308	017F 2054		BRA	P2764	
00309	*				
00310	0181 308D12BD	SWMES9	LEAX	INMSG9,PCR	2528
00311	0185 170763		LBSR	PDATA2	
00312	0188 308D15FB		LEAX	H2528,PCR	
00313	018C 9F21		STX	EPRTYP	
00314	018E 2055		BRA	P2528	
00315	*				
00316	0190 8E0400	P2508	LDX	#BUFFLO+\$0400	SET 1K END
00317	0193 201E		BRA	PP2508	REST AS 2516
00318	*				
00319	0195 8E0400	P2708	LDX	#BUFFLO+\$0400	SET 1K END
00320	0198 9F0C	PP2716	STX	BUFEND	
00321	019A 301F		LEAX	-1,X	SET END TO X3FF
00322	019C 9F02		STX	FINISH	
00323	019E 8E0000		LDX	#0	
00324	01A1 9F00		STX	START	
00325	01A3 0317		COM	FGTRIV	SET TRI-VOLT EPROM FLAG
00326	01A5 308D0F43		LEAX	SWPMT,PCR	
00327	01A9 17073F		LBSR	PDATA2	
00328	01AC 8601		LDA	#1	SET FLAG
00329	01AE 2043		BRA	MENUS	
00330	*				
00331	01B0 8E0800	P2516	LDX	#BUFFLO+\$0800	SET 2K END
00332	01B3 9F0C	PP2508	STX	BUFEND	
00333	01B5 308D0E9F		LEAX	SWPRMT,PCR	
00334	01B9 17072F		LBSR	PDATA2	
00335	01BC 8602		LDA	#2	SET FLAG
00336	01BE 2033		BRA	MENUS	
00337	*				
00338	01C0 8E0800	P2716	LDX	#BUFFLO+\$0800	SET 2K END
00339	01C3 20D3		BRA	PP2716	REST AS 2708
00340	*				
00341	01C5 8E1000	P2732	LDX	#BUFFLO+\$1000	SET 4K END
00342	01C8 9F0C		STX	BUFEND	
00343	01CA 308D0E8A		LEAX	SWPRMT,PCR	
00344	01CE 17071A		LBSR	PDATA2	
00345	01D1 8603		LDA	#3	SET FLAG
00346	01D3 201E		BRA	MENUS	
00347	*				
00348	01D5 8E2000	P2764	LDX	#BUFFLO+\$2000	SET 8K END
00349	01D8 9F0C		STX	BUFEND	
00350	01DA 308D0E7A		LEAX	SWPRMT,PCR	
00351	01DE 17070A		LBSR	PDATA2	
00352	01E1 8604		LDA	#4	SET FLAG
00353	01E3 200E		BRA	MENUS	
00354	*				
00355	01E5 8E4000	P2528	LDX	#BUFFLO+\$4000	SET 16K END
00356	01E8 9F0C		STX	BUFEND	
00357	01EA 308D0E6A		LEAX	SWPRMT,PCR	
00358	01EE 1706FA		LBSR	PDATA2	
00359	01F1 8600		LDA	#0	SET FLAG
00360	*				
00361	01F3 970E	MENUS	STA	TYPE	

00362	01F5	308D171C		LEAX	CONMSG,PCR	
00363	01F9	1706EF		LBSR	PDATA2	
00364	01FC	1706F3		LBSR	INCH	WAIT FOR OPERATOR
00365	*					
00366	01FF	32C90186	MENUX	LEAS	STACKB,U	RE-LOAD INITIAL STACK POINTER
00367	0203	308D1289		LEAX	FRAME,PCR	PRINT EPROM + ADDR.LIMITS
00368	0207	1706E1		LBSR	PDATA2	
00369	020A	9E21		LDX	EPRTYP	GET ADDR. OF EPROM TYPE MESS.
00370	020C	1706DC		LBSR	PDATA2	
00371	020F	308D12A8		LEAX	FMENU,PCR	DISPLAY OPERATIONS MENU
00372	0213	1706D5		LBSR	PDATA2	
00373	0216	1706D9		LBSR	INCH	GET FUNCTION
00374	0219	8130		CMPA	##30	
00375	021B	1027035F		LBEQ	FUNCT0	
00376	021F	8131		CMPA	##31	
00377	0221	10270574		LBEQ	FUNCT1	
00378	0225	8132		CMPA	##32	
00379	0227	10270496		LBEQ	FUNCT2	
00380	022B	8133		CMPA	##33	
00381	022D	10270465		LBEQ	FUNCT3	
00382	0231	8134		CMPA	##34	
00383	0233	2720		BEQ	FUNCT4	
00384	0235	8135		CMPA	##35	
00385	0237	102703CC		LBEQ	FUNCT5	
00386	023B	8136		CMPA	##36	
00387	023D	276E		BEQ	FUNCT6	
00388	023F	8137		CMPA	##37	
00389	0241	2773		BEQ	FUNCT7	
00390	0243	8139		CMPA	##39	
00391	0245	2772		BEQ	FUNCT9	
00392	0247	8152		CMPA	#'R	
00393	0249	102706EB		LBEQ	FUNCTR	
00394	024D	8157		CMPA	#'W	
00395	024F	102706FD		LBEQ	FUNCTW	
00396	0253	20AA		BRA	MENUX	GET FUNCTION (REPEAT IF ILLEGA
00397	*					
00398	0255	308D15AE	FUNCT4	LEAX	PFRAME,PCR	
00399	0259	17068F		LBSR	PDATA2	
00400	025C	9E21		LDX	EPRTYP	PRINT EPR. + ADDR RANGE
00401	025E	17068A		LBSR	PDATA2	
00402	0261	308D15B9		LEAX	PRGMSG,PCR	GET PROGRAM EPROM MESSAGE
00403	0265	170683		LBSR	PDATA2	PRINT IT
00404	0268	308D0EAC		LEAX	PLEPRM,PCR	GET PLACE EPROM MSG
00405	026C	17067C		LBSR	PDATA2	PRINT IT
00406	026F	308D0B64		LEAX	MSG12,PCR	GET HIT 'Y' WHEN READY MSG
00407	0273	170675		LBSR	PDATA2	PRINT IT
00408	0276	170679		LBSR	INCH	GET REPLY
00409	0279	8159		CMPA	#'Y	
00410	027B	2682		BNE	MENUX	
00411	027D	1705C6		LBSR	CRLF	
00412	0280	0D17		TST	FGTRIV	SEE IF TRI-VOLT EPROM
00413	0282	2639		BNE	EXTRIV	DO TRI-VOLT ROUTINES IF SET
00414	0284	8D65		BSR	ENTER1	GET ADDRESSES
00415	0286	17011A		LBSR	ERACHK	CHECK ERASED
00416	0289	0D1D		TST	ERFLG	
00417	028B	2705		BEQ	ERAOK	
00418	028D	170150		LBSR	PROGRX	
00419	0290	2008		BRA	DOVER	
00420	0292	17013B	ERAOK	LBSR	PROGRM	
00421	*					

00422		* LONG DELAY FOR PSU'S TO DROP			
00423		*			
00424	0295	8604	LDA	#4	
00425	0297	170169	LBSR	MLOOP	
00426	029A	170227	DOVER	LBSR	VERIFY
00427		*			
00428	029D	308D093D	FUNEND	LEAX	MSG9,PCR
00429	02A1	170647		LBSR	PDATA2
00430	02A4	1702B1		LBSR	STOP
00431	02A7	1702C9		LBSR	ENDEX
00432	02AA	16FF52		LBRA	MENUX
00433		*			
00434	02AD	170443	FUNCT6	LBSR	DUMP
00435	02B0	1702B9		LBSR	SAYDUN
00436	02B3	16FF49		LBRA	MENUX
00437		*			
00438	02B6	16FDFD	FUNCT7	LBRA	QMENU
00439		*			
00440	02B9	5F	FUNCT9	CLRB	
00441	02BA	103F06	SYSERR	OS9	F*EXIT
00442		*			
00443	02BD	8D19	EXTRIV	BSR	OPTRIV
00444	02BF	1700E1		LBSR	ERACHK
00445	02C2	0D1D		TST	ERFLG
00446	02C4	2705		BEQ	ERASOK
00447	02C6	170117		LBSR	PROGRX
00448	02C9	2003		BRA	DOVERR
00449	02CB	170102	ERASOK	LBSR	PROGRM
00450	02CE	8604	DOVERR	LDA	#04
00451	02D0	170130		LBSR	MLOOP
00452	02D3	1701EE		LBSR	VERIFY
00453	02D6	20C5		BRA	FUNEND
00454		*			
00455	02D8	308D1656	OPTRIV	LEAX	MSG08,PCR
00456	02DC	17060C		LBSR	PDATA2
00457	02DF	8E0000		LDX	#0
00458	02E2	9F00		STX	START
00459	02E4	9E0C		LDX	BUFEND
00460	02E6	301F		LEAX	-1,X
00461	02E8	9F02		STX	FINISH
00462	02EA	39		RTS	
00463		*			
00464	02EB	308D07E8	ENTER1	LEAX	MSG1,PCR
00465	02EF	1705F9		LBSR	PDATA2
00466	02F2	9E0C		LDX	BUFEND
00467	02F4	9F0A		STX	LIMIT
00468	02F6	170555		LBSR	BADDR
00469	02F9	0D1D		TST	ERFLG
00470	02FB	26EE		BNE	ENTER1
00471	02FD	1705D0		LBSR	LIMCHK
00472	0300	2409		BCC	CONT1
00473	0302	308D0801	NOTVAL	LEAX	MSG3,PCR
00474	0306	1705E2		LBSR	PDATA2
00475	0309	20E0		BRA	ENTER1
00476	030B	9F00	CONT1	STX	START
00477	030D	9F04		STX	ADDRH
00478		*			
00479	030F	308D07DC	ENTER2	LEAX	MSG2,PCR
00480	0313	1705D5		LBSR	PDATA2
00481	0316	170535		LBSR	BADDR

```

00482 00319 9F02          STX  FINISH
00483 0031B 0D1D          TST  ERFLG
00484 0031D 26F0          BNE  ENTER2
00485 0031F 1705AE        LBSR  LIMCHK      CHECK LIMIT
00486 00322 2402          BCC  CONT2
00487 00324 20DC          BRA  NOTVAL
00488 00326 9E02          LDX  FINISH      SET LIMIT TO FINISH
00489 00328 3001          LEAX 1,X
00490 0032A 9F0A          STX  LIMIT
00491 0032C 9E00          LDX  START      SEE IF START >= FINISH
00492 0032E 17059F        LBSR  LIMCHK
00493 00331 25CF          BCS  NOTVAL
00494 00333 8E4000        LDX  #BUFFHI
00495 00336 9F0A          STX  LIMIT      RESTORE LIMIT
00496 00338 39           RTS
00497 *
00498 *****
00499 * *
00500 *SPECIAL PROGRAM FOR TRI VOLT EPROMS *
00501 * *
00502 *****
00503 *
00504 00339 8D38          PGTRIV BSR  STROBL      TURN 5V ON
00505 0033B 1700B4        LBSR  PUPDLY      WAIT TO RISE
00506 0033E 8680          LDA  #80          SET CYCLE COUNT 128
00507 00340 9715          STA  COUNT
00508 00342 17FD5C        LBSR  INIT2      SET B SIDE TO O/P
00509 00345 9E00          LDX  START      GET START ADDRESS
00510 00347 9F04          STX  ADDRHI
00511 00349 9605          LDA  ADDRLO      LOOPB1
00512 0034B 9E25          LDX  PORT        GET PORT ADDRESS
00513 0034D A784          STA  0,X        SET LOW ADDRESS
00514 0034F 8D22          BSR  STROBL
00515 00351 9604          LDA  ADDRHI      GET HI ADDR <<<< ARE THESE TW
00516 00353 8D2F          BSR  STROBH      SET HI ADDR <<<< REALLY NECES
00517 00355 9E04          LDX  ADDRHI      POINT TO DATA
00518 00357 1705C2        LBSR  READBUFF    GET DATA
00519 0035A 9E25          LDX  PORT        GET PORT ADDRESS
00520 0035C A702          STA  2,X        SET TO O/P
00521 0035E 1700FA        LBSR  PGRM        PULSE OUT
00522 *
00523 * DUTY CYCLE DELAY
00524 *
00525 00361 8E0008        LDX  #DCYCLA
00526 00364 170090        LBSR  DLOOP
00527 00367 170135        LBSR  ENDCHK      INC PTR AND TEST FOR LAST
00528 0036A 25DD          BCS  LOOPB1      LOOP TILL END OF PASS
00529 0036C 0A15          DEC  COUNT
00530 0036E 26D5          BNE  LOOPB2
00531 00370 1600E3        LBRA ALLDUN
00532 *
00533 *****
00534 * *
00535 * STROBE ADDRESS AND CONTROL LATCHES ROUTINES *
00536 * *
00537 *****
00538 *
00539 00373 9F23          STROBL STX  XSTORE      SAVE X
00540 00375 9E25          LDX  PORT        GET PORT ADDRESS
00541 00377 E601          LDB  1,X        GET SIDE A C/REG

```

```

00542 0379 CA08          ORB    ##08      SET BIT 3 TO STROBE DATA ON B
00543 037B E701          STB    1,X
00544 037D C4F7          ANDB   ##F7      CLR BIT 3 FOR STROBE
00545 037F E701          STB    1,X
00546 0381 9E23          LDX    XSTORE    RESTORE X
00547 0383 39           RTS              RETURN
00548 *
00549 0384 0D0E          STROBH   TST    TYPE    CHECK FOR 2528 EPROM
00550 0386 2704          BEQ     EP2528
00551 0388 84E0          ANDA    ##E0
00552 038A 2002          BRA     HSTROB
00553 038C 84C0          EP2528  ANDA    ##C0
00554 038E 9A04          HSTROB   ORA     ADDRH    FILL IN CURRENT ADDRESS
00555 0390 9F23          STBHI    STX     XSTORE    SAVE X
00556 0392 9E25          LDX     PORT     GET PORT ADDRESS
00557 0394 A784          STA     0,X      ARM LATCH
00558 0396 E603          LDB     3,X      GET SIDE B C/REG
00559 0398 CA08          ORB     ##08      SET BIT 3 TO STROBE DATA ON A
00560 039A E703          STB     3,X
00561 039C C4F7          ANDB   ##F7      CLR BIT 3 FOR STROBE
00562 039E E703          STB     3,X
00563 03A0 9E23          LDX     XSTORE    RESTORE X
00564 03A2 39           RTS              RETURN
00565 *
00566 *****
00567 *
00568 * VERIFY EPROM IS ERASED BETWEEN LIMITS *
00569 *
00570 *****
00571 *
00572 03A3 0F1D          ERACHK   CLR     ERFLG
00573 03A5 8DCC          BSR     STROBL   FIRE LOW STROBE TO GET 5V
00574 03A7 17FCCD       LBSR     INIT1    SET B SIDE TO INPUT
00575 03AA 8D46          BSR     PUPDLY
00576 03AC DC00          LDD     START    GET START ADDR
00577 03AE DD04          STD     ADDRH    STORE FOR USE
00578 03B0 8600          NOTDUN   LDA     ##00      SET UP FOR READ
00579 03B2 8DD0          BSR     STROBH   STROBE TO LATCH
00580 03B4 9605          LDA     ADDR1    GET LOW ADDR
00581 03B6 9F23          STX     XSTORE    SAVE X
00582 03B8 9E25          LDX     PORT     GET PORT ADDRESS
00583 03BA A784          STA     0,X      ARM LATCH
00584 03BC 8DB5          BSR     STROBL   STROBE TO LATCH
00585 03BE 9E25          LDX     PORT     GET PORT ADDRESS
00586 03C0 A602          LDA     2,X      GET DATA FROM EPROM
00587 03C2 9E23          LDX     XSTORE    RESTORE X
00588 03C4 81FF          CMPA    ##FF      IS IT ERASED?
00589 03C6 1026011A     LBNE     ERR4    NO EXIT TO ERROR
00590 03CA 1700D2       LBSR     ENDCHK   INCR ADDRESS AND TEST FOR LAST
00591 03CD 25E1          BCS     NOTDUN   LOOP IF NOT LAST
00592 03CF 39           RTS
00593 *
00594 *****
00595 *
00596 * ERASE CHECK OK. PROGRAM IT! *
00597 *
00598 *****
00599 *
00600 *
00601 03D0 308D07D9     PROGRM   LEAX    MSG8,PCR   GET 'EPROM READY TO PROGRAM?'
  
```



```

00602 03D4 170514          LBSR  PDATA2      DISPLAY IT
00603 03D7 170518          LBSR  INCH        GET REPLY
00604 03DA 8159            CMPA  #'Y          IS IT A 'Y'
00605 03DC 1026FE1F        LBNE  MENUX        IF NOT PROGRAM RETURN TO OPN'S
00606 03E0 308D156C  PROGRX LEAX  MSGPGM,PCR TELL OPR ITS PROGRAMMING
00607 03E4 170504          LBSR  PDATA2
00608 03E7 9600            LDA   START        GET HI START ADDRESS
00609 03E9 9704            STA   ADDRH        STORE FOR USE
00610 *
00611 *
00612 *
00613 03EB 0D17            TST   FGTRIV        SEE IF TRI-VOLT EPROM
00614 03ED 272B            BEQ   SKIP08
00615 03EF 16FF47          LBRA  PGTRIV        IF SO JUMP TO SPECIAL ROUTINE
00616 *
00617 * 400ms DELAY FOR PSU'S TO RISE
00618 * (CAN'T BE ANY LONGER SO INTERRUPTS ARE MASKED)
00619 *
00620 03F2 1A50            PUPDLY  ORCC  #FIRQM+IRQM
00621 03F4 8EFFFF          LDX   #PWRDLY
00622 03F7 8C0000          DLOOP  CMPX  #0
00623 03FA 2704            BEQ   ENDLY3
00624 03FC 301F          LEAX  -1,X
00625 03FE 20F7          BRA   DLOOP
00626 0400 1CAF          ENDLY3 ANDCC #FF-FIRQM-IRQM
00627 0402 39            RTS
00628 *
00629 * LONG DELAY FOR PSU'S TO DROP
00630 *
00631 0403 8100          MLOOP  CMPA  #0
00632 0405 2705          BEQ   ENDLY1
00633 0407 4A            DECA
00634 0408 8D03          BSR   DELAY2
00635 040A 20F7          BRA   MLOOP
00636 040C 39          ENDLY1 RTS
00637 *
00638 040D 8EFFFF          DELAY2 LDX   #PWRDLY
00639 0410 8C0000          DLOOP3 CMPX  #0
00640 0413 2704          BEQ   ENDLY2
00641 0415 301F          LEAX  -1,X
00642 0417 20F7          BRA   DLOOP3
00643 0419 39          ENDLY2 RTS
00644 *
00645 *****
00646 *
00647 * TURN ON 25V AND ALLOW TO RISE *
00648 *
00649 *****
00650 *
00651 041A 17FF56          SKIP08 LBSR  STROBL      TURN ON 5V
00652 041D 8660          LDA   #$60      TURN ON 25V AND CS TO WRITE
00653 041F 17FF62          LBSR  STROBH
00654 0422 8DCE          BSR   PUPDLY
00655 0424 DC00          LDD   START      GET ADDRESS
00656 0426 DD04          STD   ADDRH      SET ADDR READY FOR RUN
00657 0428 9E00          LDX   START      GET BUFFER POINTER
00658 042A 17FC74          NEXT  LBSR  INIT2      SET UP PIA B SIDE FOR OUTPUT
00659 042D 9605          LDA   ADDR1      GET LO ADDR
00660 042F 9F23          STX   XSTORE    SAVE X
00661 0431 9E25          LDX   PORT      GET PORT ADDRESS

```


00662	0433	A784	STA	0,X	ARM LO ADDR LATCH
00663	0435	9E23	LDX	XSTORE	RESTORE X
00664	0437	17FF39	LBSR	STROBL	STROBE TO LOW ORDER LATCH
00665	043A	9E04	LDX	ADDRH	GET ADDRESS
00666	043C	1704DD	LBSR	READBUFF	GET DATA.
00667	043F	81FF	CMPA	##FF	SEE IF PGRM IS REQ'D
00668	0441	270F	BEQ	SKPRGM	
00669	0443	9F23	STX	XSTORE	SAVE X
00670	0445	9E25	LDX	PORT	GET PORT ADDRESS
00671	0447	A702	STA	2,X	LOAD TO EPROM
00672	0449	9E23	LDX	XSTORE	RESTORE X
00673	044B	8D0E	BSR	PGRM	PULSE OUT
00674		*			
00675		*****			
00676		*			
00677		* DUTY CYCLE DELAY ROUTINE			
00678		*			
00679		*****			
00680		*			
00681	044D	8E0008	LDX	#DCYCLB	
00682	0450	8DA5	BSR	DLOOP	DUTY CYCLE DELAY
00683	0452	8D4B	SKPRGM	BSR	ENDCHK
00684	0454	25D4	BCS	NEXT	LAST ADDRESS?
00685		*			NOT FINISHED GET NEXT
00686		*			
00687	0456	4F	ALLDUN	CLRA	SEND 'PROG DONE' MSG AND RETUR
00688	0457	17FF36	LBSR	STBHI	
00689	045A	39	RTS		
00690		*			
00691		*			
00692		*****			
00693		*			
00694		* GENERATE A PROGRAM PULSE *			
00695		*			
00696		*****			
00697		*			
00698	045B	0D17	PGRM	TST	FGTRIV
00699	045D	2620	BNE	PGR08	SELECT WHICH PGRM PULSE
00700	045F	8660	LDA	##60	START WITH OP LO
00701	0461	17FF20	LBSR	STROBH	
00702	0464	86E0	LDA	##E0	SET FOR PGRM PULSE HI
00703	0466	17FF1B	LBSR	STROBH	LOAD IT
00704	0469	8660	LDA	##60	PULSE LO
00705	046B	17FF16	LBSR	STROBH	LOAD IT
00706	046E	9F23	STX	XSTORE	SAVE X
00707	0470	9E25	LDX	PORT	GET PORT ADDRESS
00708	0472	A602	LDA	2,X	DUMMY READS TO CLR FLAGS
00709		*			
00710	0474	A603	TSTLP1	LDA	3,X
00711	0476	8480	ANDA	##80	TEST B REG INT FLAG FOR END OF
00712	0478	27FA	BEQ	TSTLP1	
00713	047A	A602	LDA	2,X	DUMMY READ TO CLR FLAG
00714	047C	9E23	LDX	XSTORE	RESTORE X
00715	047E	39	RTS		RETURN WHEN DONE
00716		*			
00717	047F	8620	PGR08	LDA	##20
00718	0481	17FF00	LBSR	STROBH	
00719	0484	86A0	LDA	##A0	
00720	0486	17FEFB	LBSR	STROBH	
00721	0489	8620	LDA	##20	

00722	048B 17FEF6		LBSR	STROBH	
00723	048E 9F23		STX	XSTORE	SAVE X
00724	0490 9E25		LDX	PORT	GET PORT ADDRESS
00725	0492 A684		LDA	0,X	DUMMY READ
00726	*				
00727	0494 A601	PLS08	LDA	1,X	
00728	0496 8480		ANDA	##80	
00729	0498 27FA		BEQ	PLS08	
00730	049A A684		LDA	0,X	DUMMY RD TO CLR FLG
00731	049C 9E23		LDX	XSTORE	RESTORE X
00732	049E 39		RTS		
00733	*				
00734	*****				
00735	*				*
00736	* CHECK FOR LAST ADDRESS AND INCREMENT ADDRESS IF NOT *				
00737	*				*
00738	*****				
00739	*				
00740	049F 9F08	ENDCHK	STX	SAVEX	SAVE X REG
00741	04A1 9E04		LDX	ADDRH	GET RUNNING ADDRESS
00742	04A3 9C02		CMPX	FINISH	LAST ADDRESS?
00743	04A5 2709		BEQ	DONE	SKIP IF LAST
00744	04A7 3001		LEAX	1,X	
00745	04A9 9F04		STX	ADDRH	LOAD NEW ADDR
00746	04AB 1A01		ORCC	#CARRY	SET CARRY TO SHOW NOT DONE
00747	04AD 9E08		LDX	SAVEX	RESTORE X REG
00748	04AF 39		RTS		RETURN
00749	*				
00750	04B0 1CFE	DONE	ANDCC	##FF-CARRY	CLR CARRY TO SHOW ALL DONE
00751	04B2 9E08		LDX	SAVEX	RESTORE X REG
00752	04B4 39		RTS		RETURN
00753	*				
00754	*****				
00755	*				*
00756	* READ EPROM INTO BUFFER *				
00757	*				*
00758	*****				
00759	*				
00760	04B5 8D6B	READ	BSR	SETADD	SET UP ADDRESSES
00761	04B7 170083	RLOOP	LBSR	SETUPR	SET UP FOR READ
00762	04BA 17046B		LBSR	RITEBUFF	LOAD TO BUFFER
00763	04BD 3001		LEAX	1,X	STEP BUFFER POINTER
00764	04BF 8DDE		BSR	ENDCHK	INC ADDR AND TEST FOR LAST
00765	04C1 25F4		BCS	RLOOP	LOOP IF NOT DONE
00766	04C3 39		RTS		RETURN WHEN DONE
00767	*				
00768	04C4 8D5C	VERIFY	BSR	SETADD	
00769	04C6 8D75	VLOOP	BSR	SETUPR	SET UP FOR READ
00770	04C8 3402		PSHS	A	
00771	04CA 17044F		LBSR	READBUFF	
00772	04CD A1E0		CMPA	,S+	VERIFY DATA
00773	04CF 263C		BNE	ERR3	EXIT IF NOT GOOD
00774	04D1 3001		LEAX	1,X	STEP BUFFER POINTER
00775	04D3 8DCA		BSR	ENDCHK	INC ADDR AND TEST FOR LAST
00776	04D5 25EF		BCS	VLOOP	BACK FOR MORE
00777	04D7 39		RTS		RETURN WHEN DONE
00778	*				
00779	04D8 308D062B	ERR1	LEAX	MSG3,PCR	GET 'OUT OF RANGE' MSG
00780	04DC 17040C		LBSR	PDATA2	DISPLAY IT
00781	04DF 3262	FNERR1	LEAS	2,S	

```

00782 04E1 16FD1B          LBRA  MENUX      RESTART
00783      *
00784 04E4 0F1D          ERR4  CLR    ERFLG
00785 04E6 031D          COM    ERFLG      ERFLG=FF IF ERROR
00786 04E8 308D0659      LEAX   MSG4,PCR
00787 04EC 1703FC      LBSR   PDATA2
00788 04EF 3044          LEAX   ADDRH,U
00789 04F1 1703D4      LBSR   OUT4HS      DISPLAY FAILED ADDRESS
00790 04F4 17034F      LBSR   CRLF
00791 04F7 8D5F          BSR    STOP      CLR LATCH
00792 04F9 308D0694      LEAX   MSG6,PCR
00793 04FD 1703EB      LBSR   PDATA2
00794 0500 1703EF      LBSR   INCH
00795 0503 8159          CMPA   #'Y
00796 0505 2705          BEQ    ABERR4
00797 0507 17033C      LBSR   CRLF
00798 050A 20D3          BRA    FNERR1      RETURN TO MAIN MENU
00799 050C 39          ABERR4 RTS
00800      *
00801 050D 308D065A      ERR3  LEAX   MSG5,PCR
00802      *
00803 0511 1703D7      ERREX  LBSR   PDATA2
00804 0514 3044          LEAX   ADDRH,U
00805 0516 1703AF      LBSR   OUT4HS      DISPLAY ERROR MSG AND FAILED A
00806 0519 8D3D          BSR    STOP      CLR LATCH
00807 051B 8D56          BSR    ENDEX
00808 051D 3262          LEAS   2,S
00809 051F 16FCDD      LBRA  MENUX      RETURN TO MAIN MENU
00810      *
00811 0522 17FE4E      SETADD LBSR   STROBL
00812 0525 17FECA      LBSR   PUPDLY      TURN ON PWR AND WAIT
00813 0528 17FB4C      LBSR   INIT1      SET B SIDE TO INPUTS
00814 052B 0F00          CLR    START
00815 052D 0F01          CLR    START+1      SET START ADDR TO 0
00816 052F 9E0C          LDX    BUFEND
00817 0531 301F          LEAX   -1,X      END -1
00818 0533 9F02          STX    FINISH      SET FINISH = END OF BUFFER
00819 0535 0F04          CLR    ADDRH
00820 0537 0F05          CLR    ADDRRL
00821 0539 8E0000      LDX    #BUFFLO      SET START POINTER
00822 053C 39          RTS
00823      *
00824 053D 8600          SETUPR LDA    #000      SET UP FOR READ
00825 053F 17FE42      LBSR   STROBH
00826 0542 9605          LDA    ADDRRL      PUT OUT LO ADDR
00827 0544 9F23          STX    XSTORE      SAVE X
00828 0546 9E25          LDX    PORT      GET PORT ADDRESS
00829 0548 A784          STA    0,X
00830 054A 9E23          LDX    XSTORE      RESTORE X
00831 054C 17FE24      LBSR   STROBL
00832 054F 9F23          STX    XSTORE      SAVE X
00833 0551 9E25          LDX    PORT      GET PORT ADDRESS
00834 0553 A602          LDA    2,X      GET DATA
00835 0555 9E23          LDX    XSTORE      RESTORE X
00836 0557 39          RTS
00837      *
00838      *****
00839      *
00840      *TURN OFF THE POWER WHEN COMPLETE *
00841      *

```

```

00842      *****
00843      *
00844      0558 4F          STOP      CLRA
00845      0559 17FE17      LBSR      STROBL
00846      055C 17FE31      LBSR      STBHI
00847      055F 9F23        STX        XSTORE      SAVE X
00848      0561 9E25        LDX        PORT        GET PORT ADDRESS
00849      0563 A601        LDA        1,X
00850      0565 84F7        ANDA      #F7
00851      0567 A701        STA        1,X        SET 5V OFF
00852      0569 9E23        LDX        XSTORE      RESTORE X
00853      056B 39          RTS
00854      *
00855      *****
00856      *
00857      * TELL THE OPERATOR THAT THE JOB IS DONE *
00858      *
00859      *****
00860      *
00861      056C 308D12EA      SAYDUN    LEAX    DUNMSG,PCR
00862      0570 170378      LBSR      PDATA2
00863      0573 308D139E      ENDEX    LEAX    CONMSG,PCR
00864      0577 170371      LBSR      PDATA2
00865      057A 170375      LBSR      INCH
00866      057D 39          RTS
00867      *
00868      USE      UPRM2D
00869      TTL      EPROM PROGRAMMER PART TWO
00870      *
00871      *****
00872      *
00873      * FILL THE BUFFER WITH A SPECIFIED CHARACTER *
00874      *
00875      *****
00876      *
00877      057E          FUNCT0      EQU      *
00878      *
00879      057E 308D0736      FILBUF    LEAX    FILMES,PCR
00880      0582 170366      LBSR      PDATA2      PROMPT FOR FILL CHAR.
00881      0585 8E4000      LDX        #BUFFHI    SET LIMIT TO BUFFHI
00882      0588 9F0A        STX        LIMIT
00883      058A 1702D4      LBSR      BYTE        GET HEX BYTE
00884      058D 971E        STA        FILCAR      SAVE IT
00885      058F 0D1D        TST        ERFLG
00886      0591 26EB        BNE        FILBUF
00887      0593 308D0540      ENTR1    LEAX    MSG1,PCR      ASK FOR START ADDRESS
00888      0597 170351      LBSR      PDATA2
00889      059A 1702B1      LBSR      BADDR        GET IT
00890      059D 0D1D        TST        ERFLG        NON HEX ?
00891      059F 26F2        BNE        ENTR1
00892      05A1 17032C      LBSR      LIMCHK      CHECK.WITHIN BUFFER LIMITS
00893      05A4 2506        BCS        LIMER1
00894      05A6 9F00        STX        START      SAVE START
00895      05A8 9F04        STX        ADDRH      STORE START ADDR
00896      05AA 200E        BRA        ENTR2
00897      05AC 308D0557      LIMER1    LEAX    MSG3,PCR
00898      05B0 170338      LBSR      PDATA2
00899      05B3 8E4000      LDX        #BUFFHI    RESTORE LIMIT
00900      05B6 9F0A        STX        LIMIT
00901      05B8 20D9        BRA        ENTR1

```

```

00902 05BA 308D0531  ENTR2  LEAX  MSG2,PCR  ASK FOR END RANGE
00903 05BE 17032A      LBSR  PDATA2
00904 05C1 17028A      LBSR  BADDR
00905 05C4 9F02        STX   FINISH
00906 05C6 0D1D        TST   ERFLG      VALID HEX ?
00907 05C8 26F0        BNE   ENTR2
00908 05CA 170303      LBSR  LIMCHK      CHECK WITHIN BUFFER LIMITS
00909 05CD 2502        BCS   LIMER2
00910 05CF 2009        BRA   OK
00911 05D1 308D0532  LIMER2  LEAX  MSG3,PCR
00912 05D5 170313      LBSR  PDATA2
00913 05D8 20B9        BRA   ENTR1
00914 05DA 9E02        OK      LDX   FINISH      CHECK START>=FINISH
00915 05DC 3001        LEAX  1,X
00916 05DE 9F0A        STX   LIMIT
00917 05E0 9E00        LDX   START
00918 05E2 1702EB      LBSR  LIMCHK
00919 05E5 25C5        BCS   LIMER1
00920 05E7 9E02        LDX   FINISH
00921 05E9 3001        LEAX  1,X
00922 05EB 9F02        STX   FINISH      BUMP UP ONE
00923 05ED 9E00        LDX   START      GET BEGIN ADDRESS
00924 05EF 961E        LDA   FILCAR
00925 05F1 170334      CLOOPA  LBSR  RITEBUFF
00926 05F4 3001        LEAX  1,X
00927 05F6 9C02        CMPX  FINISH      CHK.FOR END
00928 05F8 26F7        BNE   CLOOPA
00929 05FA 17FF6F      FILDUN  LBSR  SAYDUN
00930 05FD 16FBFF      LBRA  MENUX
00931 *
00932 *****
00933 *
00934 * EXAMINE & CHANGE THE BUFFER *
00935 *
00936 *****
00937 *
00938 0600 308D049B  OTLIMIT  LEAX  MERMSG,PCR
00939 0604 1702E4      LBSR  PDATA2
00940 *
00941 0607          FUNCT5  EQU   *
00942 *
00943 0607 308D06FA  INSERT  LEAX  INSMMSG,PCR
00944 060B 1702DD      LBSR  PDATA2
00945 060E 8E4000      LDX   #BUFFHI      SET UPPER LIMIT OF BUFFER
00946 0611 9F0A        STX   LIMIT
00947 0613 170238      LBSR  BADDR
00948 0616 17022D      LBSR  CRLF
00949 0619 0D1D        TST   ERFLG
00950 061B 26EA        BNE   INSERT
00951 *
00952 * TEST TO SEE IF STARTING ADDRESS IS WITHIN LIMITS
00953 *
00954 061D 9E1F          LDX   XHI
00955 061F 1702AE      LBSR  LIMCHK
00956 0622 25DC        BCS   OTLIMIT
00957 *
00958 0624 17021F      CHA51  LBSR  CRLF
00959 0627 30C81F      LEAX  XHI,U      GET AND RE-PRINT ADDRESS
00960 062A 17029B      LBSR  OUT4HS
00961 062D 9E1F          LDX   XHI      GET DATA

```

00962	062F	1702EA		LBSR	READBUFF	
00963	0632	3001		LEAX	1,X	
00964	0634	9F1F		STX	XHI	
00965	0636	170287		LBSR	OUT2HAS	AND PRINT IT
00966	0639	0F1D		CLR	ERFLG	
00967	063B	1702B4		LBSR	INCH	GET NEW DATA
00968	063E	8120		CMPA	##20	IF SPACE GET NEXT
00969	0640	2731		BEQ	CHA81	
00970	0642	8155		CMPA	#'U	IF 'UP' GET PREVIOUS ADDRESS
00971	0644	2722		BEQ	CHA71	
00972	0646	815E		CMPA	#'^	
00973	0648	271E		BEQ	CHA71	
00974	064A	810D		CMPA	##0D	IF 'RET' RETURN TO MENU
00975	064C	1027FBAF		LBEQ	MENUX	
00976	0650	170245		LBSR	INHEXX	
00977	0653	0D1D		TST	ERFLG	
00978	0655	2609		BNE	NONHEX	
00979	0657	170209		LBSR	BYTE+2	GET NEW DATA
00980	065A	0D1D		TST	ERFLG	
00981	065C	2602		BNE	NONHEX	
00982	065E	202D		BRA	CHA61	STORE NEW DATA
00983	0660	9E1F	NONHEX	LDX	XHI	
00984	0662	301F		LEAX	-1,X	
00985	0664	9F1F		STX	XHI	
00986	0666	20BC		BRA	CHA51	BACK IT UP AND TRY AGAIN
00987	0668	301E	CHA71	LEAX	-2,X	
00988	066A	8CFFFF		CMPX	##FFFF	
00989	066D	270B		BEQ	LOLIMT	
00990	066F	9F1F		STX	XHI	
00991	0671	20B1		BRA	CHA51	LOOP FOR MORE
00992	*					
00993	0673	8C4000	CHA81	CMPX	#BUFFHI	SEE IF OUTSIDE OF BUFFER LIMIT
00994	0676	270F		BEQ	HILIMT	
00995	0678	20AA		BRA	CHA51	O.K....GET NEXT ONE
00996	067A	3001	LOLIMT	LEAX	1,X	
00997	067C	9F1F		STX	XHI	MOVE FORWARD TO '0000'
00998	067E	308D041D	BUFLMT	LEAX	MERMSG,PCR	'BUFFER LIMITS EXCEEDED'
00999	0682	170266		LBSR	PDATA2	
01000	0685	209D		BRA	CHA51	RE-PRINT CURRENT LINE
01001	0687	301F	HILIMT	LEAX	-1,X	
01002	0689	9F1F		STX	XHI	BACK UP TO TOP LIMIT OF BUFEE
01003	068B	20F1		BRA	BUFLMT	
01004	*					
01005	068D	9E1F	CHA61	LDX	XHI	
01006	068F	301F		LEAX	-1,X	
01007	0691	170294		LBSR	RITEBUFF	STORE NEW DATA
01008	0694	208E		BRA	CHA51	AND GET NEXT
01009	*					
01010	*****					
01011	*					
01012	*	VERIFY EPROM AGAINST THE BUFFER				
01013	*					
01014	*****					
01015	*					
01016	0696		FUNCT3	EQU	*	
01017	*					
01018	0696	308D1133	VERPRM	LEAX	VERMSG,PCR	GET VERIFY EPROM MESSAGE
01019	069A	17024E		LBSR	PDATA2	PRINT IT
01020	069D	308D0A77		LEAX	PLEPRM,PCR	GET PLACE EPROM MSG
01021	06A1	170247		LBSR	PDATA2	PRINT IT


```

01022 06A4 308D072F      LEAX MSG12,PCR  GET READY TO CONTINUE MSG
01023 06A8 170240      LBSR PDATA2    PRINT IT
01024 06AB 170244      LBSR INCH       GET REPLY
01025 06AE 8159        CMPA #'Y
01026 06B0 260C        BNE XMENU      RETURN TO MENU IF NOT 'Y'
01027 06B2 170191      LBSR CRLF
01028 06B5 17FE0C      LBSR VERIFY    DO VERIFY ROUTINE (WILL EXIT I
01029 06B8 17FE9D      LBSR STOP      CLEAR LATCH
01030 06BB 17FEAE      LBSR SAYDUN
01031 06BE 16FB3E      XMENU LBRA MENUX
01032 *
01033 *****
01034 * *
01035 * COPY AN EPROM INTO THE BUFFER *
01036 * *
01037 *****
01038 *
01039 06C1      FUNCT2 EQU *
01040 *
01041 06C1 308D10D4  CPYPRM LEAX CPYMSG,PCR  GET COPY EPROM MESSAGE
01042 06C5 170223  LBSR PDATA2    PRINT IT
01043 06C8 308D0A4C  LEAX PLEPRM,PCR  GET PLACE EPROM MSG
01044 06CC 17021C  LBSR PDATA2    PRINT IT
01045 06CF 308D0704  LEAX MSG12,PCR  GET READY TO CONTINUE MSG
01046 06D3 170215  LBSR PDATA2    PRINT IT
01047 06D6 170219  LBSR INCH       GET REPLY
01048 06D9 8159    CMPA #'Y
01049 06DB 260C    BNE YMENU      RETURN TO MENU IF NOT 'Y'
01050 06DD 170166  LBSR CRLF
01051 06E0 17FDD2  LBSR READ
01052 06E3 17FE72  LBSR STOP      CLR LATCH
01053 06E6 17FE83  LBSR SAYDUN
01054 06E9 16FB13  YMENU LBRA MENUX
01055 *
01056 *****
01057 * *
01058 * FORMATTED DUMP *
01059 * *
01060 *****
01061 *
01062 06EC 308D03AF  OUTLIM LEAX MERMSG,PCR  'BUFFER LIMITS EXCEEDED'
01063 06F0 1701F8  LBSR PDATA2
01064 06F3 308D056B  DUMP  LEAX DMPMSG,PCR
01065 06F7 1701F1  LBSR PDATA2
01066 06FA 8E4000  LDX  #BUFFHI
01067 06FD 9F0A    STX  LIMIT      SET LIMIT TO END OF BUFFER
01068 06FF 17014C  LBSR BADDDR
01069 0702 0D1D    TST  ERFLG
01070 0704 2674    BNE  TRYAGN
01071 0706 9F0F    STX  SAVEXA      SAVE START ADDRESS
01072 0708 9F1A    STX  STLINE     ASCII LINE START
01073 070A 1701C3  LBSR LIMCHK
01074 070D 25DD    BCS  OUTLIM
01075 070F 170134  LBSR CRLF
01076 0712 8D6F    MORE  BSR  LINEF
01077 0714 8610    LDA  #10
01078 0716 9715    STA  COUNT
01079 0718 8610    LINLOP LDA  #10      DO 16 X 16 DUMP
01080 071A 9716    STA  COUNT+1
01081 *

```

```

01082      * CHECK TO SEE IF DUMP REMAINS WITHIN BUFFER LIMITS
01083      *
01084      071C 8E000F          LDX    ##000F      NUMBER OF BYTES TO BE DUMPED
01085      071F 9F08          STX    SAVEX       STORE IT FOR 16 BIT ADD
01086      0721 9E0F          LDX    SAVEXA      GET CURRENT ADDRESS POINTER
01087      0723 9F23          STX    XSTORE     STORE IT FOR 16 BIT ADD
01088      0725 1701B5        LBSR    ADDEM      DO 16 BIT ADD
01089      0728 1701A5        LBSR    LIMCHK     OUT OF LIMITS?
01090      072B 25BF          BCS    OUTLIM     YES!
01091      *
01092      072D 304F          LEAX    SAVEXA,U
01093      072F 170196        LBSR    OUT4HS
01094      0732 9E0F          LDX    SAVEXA      BINLOP
01095      0734 1701E5        LBSR    READBUFF
01096      0737 3001          LEAX    1,X
01097      0739 9F0F          STX    SAVEXA
01098      073B 170182        LBSR    OUT2HAS
01099      073E 0A16          DEC    COUNT+1     OUT PUT HEX BYTE AND SPACE
01100      0740 26F0          BNE    BINLOP     DO 16 BYTES PER LINE
01101      0742 8D4A          BSR     SPACES    ASCII
01102      0744 9E1A          LDX    STLINE     GTSTRT
01103      0746 C610          LDB     ##10      16 CHARS
01104      0748 1701D1        LBSR    READBUFF  OUT
01105      074B 8120          CMPA    ##20
01106      074D 2D04          BLT     NOPRNT     NOT PRINTABLE
01107      074F 817E          CMPA    ##7E
01108      0751 2D02          BLT     OUT1       PRINT CHAR.
01109      0753 862E          LDA     #'.'      PRINT A '.'
01110      0755 1701B1        LBSR    OUTCH     OUT1
01111      0758 3001          LEAX    1,X      PRINT ASCII
01112      075A 5A           OUT2      DECB
01113      075B 26EB          BNE     OUT        LOOP BACK FOR MORE
01114      075D 9F1A          STX    STLINE
01115      075F 8D22          BSR     LINEF     CONTIN
01116      0761 0A15          DEC    COUNT     FOR 16 LINES
01117      0763 26B3          BNE     LINLOP
01118      0765 308D0326      LEAX    MORMSG,PCR
01119      0769 17017F        LBSR    PDATA2
01120      076C 170183        LBSR    INCH
01121      076F 8159          CMPA    #'Y
01122      0771 1026FA8A      LBNE    MENUX
01123      0775 1700CE        LBSR    CRLF
01124      0778 2098          BRA     MORE     PLAY IT AGAIN SAM!
01125      *
01126      077A 1700C9        LBSR    CRLF     TRYAGN
01127      077D 1700C6        LBSR    CRLF
01128      0780 16FF70        LBRA    DUMP
01129      *
01130      0783 860D          LDA     ##0D     LINEF
01131      0785 170181        LBSR    OUTCH
01132      0788 860A          LDA     ##0A
01133      078A 17017C        LBSR    OUTCH
01134      078D 39           RTS
01135      *
01136      078E 8620          LDA     ##20     SPACES
01137      0790 170176        LBSR    OUTCH
01138      0793 8620          LDA     ##20     SPACE
01139      0795 170171        LBSR    OUTCH
01140      0798 39           RTS
01141      *

```

```

01142      *****
01143      * MOVE DATA WITHIN BUFFER *
01144      *****
01145      *
01146      0799          FUNCT1      EQU      *
01147      *
01148      0799 308D110A      MOVE      LEAX      MMSG1,PCR      PROMPT FOR SOURCE
01149      079D 17014B          LBSR      PDATA2
01150      07A0 8E4000          LDX       #BUFFHI
01151      07A3 9F0A          STX        LIMIT          SET UP LIMITS
01152      07A5 1700A6          LBSR      BADDR          GET ADDRESS
01153      07A8 9F0F          STX        SAVEXA        STORE AS 'FROM ADDRESS'
01154      07AA 0D1D          TST        ERFLG
01155      07AC 24EB          BNE        MOVE
01156      07AE 17011F          LBSR      LIMCHK
01157      07B1 240A          BCC        TOADD
01158      07B3 308D0350          LEAX      MSG3,PCR
01159      07B7 170131          LBSR      PDATA2
01160 W 07BA 16FFDC          LBRA      MOVE          OUT OF LIMITS...TRY AGAIN
01161      07BD 308D112A      TOADD      LEAX      MMSG2,PCR      PROMPT FOR DESTINATION
01162      07C1 170127          LBSR      PDATA2
01163      07C4 170087          LBSR      BADDR          GET ADDRESS
01164      07C7 0D1D          TST        ERFLG
01165 W 07C9 1026FFCC          LBNE      MOVE          START OVER
01166      07CD 170100          LBSR      LIMCHK
01167      07D0 240A          BCC        TOOK
01168      07D2 308D0331          LEAX      MSG3,PCR
01169      07D6 170112          LBSR      PDATA2
01170 W 07D9 16FFBD          LBRA      MOVE          START OVER
01171      07DC 9F11          TOOK      STX        SAVEXB        STORE THE 'TO ADDRESS'
01172      07DE 308D111E      MOVSI2    LEAX      SZMSG1,PCR      PROMPT FOR SIZE OF MOVE
01173      07E2 170106          LBSR      PDATA2
01174 W 07E5 170066          LBSR      BADDR
01175      07E8 0D1D          TST        ERFLG
01176 W 07EA 1026FFAB          LBNE      MOVE          START OVER
01177      07EE 9F13          STX        SAVEXC        STORE COUNT
01178      *
01179      * ENSURE THAT MOVE STAYS WITHIN BUFFER LIMITS
01180      *
01181      07F0 301F          BUFLIM    LEAX      -1,X          ONE LESS BYTE FOR LIMIT CHECK
01182      07F2 9F08          STX        SAVEX          STORE IT FOR 16 BIT ADD
01183      07F4 9E0F          LDX        SAVEXA        GET 'FROM' ADDRESS
01184      07F6 9F23          STX        XSTORE        STORE IT FOR 16 BIT ADD
01185      07F8 1700E2          LBSR      ADDEM
01186      07FB 1700D2          LBSR      LIMCHK        CHECK TO SEE IF WITHIN BUFFER
01187      07FE 2512          BCS        MEROR        OUT OF BUFFER LIMITS
01188      0800 9E13          LDX        SAVEXC        GET NUMBER OF BYTES TO BE MOVE
01189      0802 301F          LEAX      -1,X          ONE LESS BYTE FOR LIMIT CHECK
01190      0804 9F08          STX        SAVEX          STORE IT FOR 16 BIT ADD
01191      0806 9E11          LDX        SAVEXB        GET 'TO' ADDRESS
01192      0808 9F23          STX        XSTORE        STORE IT FOR 16 BIT ADD
01193      080A 1700D0          LBSR      ADDEM
01194      080D 1700C0          LBSR      LIMCHK        CHECK TO SEE IF WITHIN BUFFER
01195      0810 240A          BCC        MVLOOP        EVERYTHING IS GO IF IT GOT THI
01196      0812 308D0289      MEROR      LEAX      MERMSG,PCR
01197      0816 1700D2          LBSR      PDATA2
01198      0819 16FF7D          LBRA      MOVE
01199      081C 9E0F          MVLOOP    LDX        SAVEXA
01200
01201      081E 1700FB          LBSR      READBUFF

```

01202	0821	3001		LEAX	1,X	
01203	0823	9F0F		STX	SAVEXA	MOVE TILL COUNT DONE
01204	0825	9E11		LDX	SAVEXB	
01205	0827	8C4000		CMPX	#BUFFHI	
01206	082A	27E6		BEQ	MEROR	
01207	082C	2000		BRA	STORIT	O.K. TO STORE
01208	082E	1700F7	STORIT	LBSR	RITEBUFF	
01209	0831	3001		LEAX	1,X	
01210	0833	9F11		STX	SAVEXB	
01211	0835	9E13		LDX	SAVEXC	
01212	0837	301F		LEAX	-1,X	
01213	0839	9F13		STX	SAVEXC	
01214	083B	8C0000		CMPX	#0	
01215	083E	26DC		BNE	MVLOOP	
01216	0840	17FD29	DUNIT	LBSR	SAYDUN	
01217	0843	16F9B9		LBRA	MENUX	MOVE AND ASK AGAIN
01218		*				
01219	0846	308D02F8	CRLF	LEAX	CRLF1,PCR	
01220	084A	17009E		LBSR	PDATA2	
01221	084D	39		RTS		
01222		*				
01223		*****				
01224		* *				
01225		* BUILD A HEX ADDRESS *				
01226		* *				
01227		*****				
01228		*				
01229	084E	8D11	BADDR	BSR	BYTE	READ 2 BYTES
01230	0850	0D1D		TST	ERFLG	
01231	0852	260C		BNE	ENDIT	ERROR
01232	0854	971F		STA	XHI	
01233	0856	8D09		BSR	BYTE	
01234	0858	0D1D		TST	ERFLG	
01235	085A	2604		BNE	ENDIT	
01236	085C	9720		STA	XLOW	
01237	085E	9E1F		LDX	XHI	
01238	0860	39	ENDIT	RTS		
01239		*				
01240		*****				
01241		* *				
01242		* INPUT BYTE *				
01243		* *				
01244		*****				
01245		*				
01246	0861	8D2B	BYTE	BSR	INHEX	GET 1'ST CHAR
01247	0863	48		ASLA		
01248	0864	48		ASLA		
01249	0865	48		ASLA		
01250	0866	48		ASLA		
01251	0867	1F89		TFR	A,B	
01252	0869	0D1D		TST	ERFLG	
01253	086B	2610		BNE	FINIS	ERROR
01254	086D	8D1F		BSR	INHEX	GET 2'ND CHAR
01255	086F	0D1D		TST	ERFLG	
01256	0871	260A		BNE	FINIS	ERROR
01257	0873	3404		PSHS	B	
01258	0875	ABE0		ADDA	,S+	
01259	0877	1F89		TFR	A,B	
01260	0879	DB1C		ADDB	CKSM	UPDATE CKSM.
01261	087B	D71C		STB	CKSM	

```

01262 087D 39          FINIS      RTS
01263      *
01264 087E 44          OUTHL      LSRA          OUT LEFT DIGIT
01265 087F 44          LSRA
01266 0880 44          LSRA
01267 0881 44          LSRA
01268 0882 840F          OUTHR      ANDA    ##F          OUT HEX RIGHT
01269 0884 8B30          ADDA    ##30
01270 0886 8139          CMPA    ##39
01271 0888 2302          BLS      OUTCH1
01272 088A 8B07          ADDA    #7
01273 088C 207B          OUTCH1    BRA      OUTCH
01274      *
01275      *****
01276      *
01277      * INPUT A HEX CHARACTER *
01278      *
01279      *****
01280      *
01281 088E 0F1D          INHEX      CLR      ERFLG
01282 0890 8D60          BSR      INCH
01283 0892 810D          CMPA    ##0D
01284 0894 1027F967      LBEQ     MENUX          CR THEN BACK TO MENUE
01285 0898 8030          INHEXX    SUBA    ##30
01286 089A 2B0F          BMI      NOTHEX
01287 089C 8109          CMPA    #9
01288 089E 2F0A          BLE      IN1HG
01289 08A0 8111          CMPA    ##11
01290 08A2 2B07          BMI      NOTHEX
01291 08A4 8116          CMPA    ##16
01292 08A6 2E03          BGT      NOTHEX
01293 08A8 8007          SUBA    #7
01294 08AA 39          IN1HG      RTS
01295      *
01296 08AB 308D050A      NOTHEX    LEAX     NOHEXM,PCR
01297 08AF 8D3A          BSR      PDATA2
01298 08B1 8D93          BSR      CRLF
01299 08B3 031D          COM      ERFLG
01300 08B5 39          RTS
01301      *
01302 08B6 A680          OUT2H      LDA      ,X+          O/P 2 HEX CHAR
01303 08B8 3402          PSHS      A
01304 08BA 8DC2          BSR      OUTHL
01305 08BC 3502          PULS      A
01306 08BE 20C2          BRA      OUTHR
01307      *
01308 08C0 3412          OUT2HAS    PSHS      A,X
01309 08C2 30E4          LEAX      ,S
01310 08C4 8D04          BSR      OUT2HS
01311 08C6 3592          PULS      A,X,PC
01312      *
01313 08C8 8DEC          OUT4HS     BSR      OUT2H
01314 08CA 8DEA          OUT2HS     BSR      OUT2H
01315 08CC 8620          OUTS      LDA      ##20
01316 08CE 20BC          BRA      OUTCH1
01317      *
01318      *****
01319      *
01320      * CHECK 16 BIT LIMIT IN 'LIMIT', CARRY SET IF X REG > OR = *
01321      *

```

```

01322      *****
01323      *
01324      08D0 9F08      LIMCHK      STX      SAVEX
01325      08D2 3406      PSHS      D
01326      08D4 DC0A      LDD      LIMIT
01327      08D6 830001    SUBD      #1
01328      08D9 9308      SUBD      SAVEX
01329      08DB 3586      PULS      D,PC
01330      *
01331      * 16 BIT ADD
01332      *
01333      08DD 3406      ADDEM      PSHS      D
01334      08DF DC23      LDD      XSTORE
01335      08E1 D308      ADDD      SAVEX
01336      08E3 1F01      TFR      D,X
01337      08E5 3586      PULS      D,PC
01338      *
01339      USE      UPRM3D
01340      TTL      EPROM PROGRAMMER PART THREE
01341      *
01342      *****
01343      *
01344      * PRINT DATA POINTED TO BY INDEX REGISTER *
01345      *
01346      *****
01347      *
01348      08E7 8D20      PDATA1      BSR      OUTCH
01349      08E9 3001      LEAX      1,X
01350      08EB A684      PDATA2      LDA      0,X
01351      08ED 8104      CMPA      #4      END OF STRING CHAR.
01352      08EF 26F6      BNE      PDATA1
01353      08F1 39      RTS
01354      *
01355      *****
01356      *
01357      *
01358      08F2 3432      INCH      PSHS      A,X,Y
01359      08F4 30E4      LEAX      ,S
01360      08F6 108E0001  LDY      #1
01361      08FA 8602      LDA      #2
01362      08FC 103F89    OS9      I$READ
01363      08FF 1025F9B7  LBCCS    SYSERR
01364      0903 3502      PULS      A
01365      0905 847F      ANDA      #$7F
01366      0907 35B0      PULS      X,Y,PC
01367      *
01368      0909 3432      OUTCH      PSHS      A,X,Y
01369      090B 30E4      LEAX      ,S
01370      090D 108E0001  LDY      #1
01371      0911 8602      LDA      #2
01372      0913 103F8A    OS9      I$WRIT
01373      0916 1025F9A0  LBCCS    SYSERR
01374      091A 35B2      PULS      A,X,Y,PC
01375      *
01376      091C 3424      READBUFF PSHS      B,Y
01377      091E 31C901D6  LEAY      BUFFER,U
01378      0922 1F10      TFR      X,D
01379      0924 A6AB      LDA      D,Y
01380      0926 35A4      PULS      B,Y,PC
01381      *

```


01382	0928 3426	RITEBUFF	PSHS	A,B,Y
01383	092A 31C901D6		LEAY	BUFFER,U
01384	092E 1F10		TFR	X,D
01385	0930 31AB		LEAY	D,Y
01386	0932 3502		PULS	A
01387	0934 A7A4		STA	,Y
01388	0936 35A4		PULS	B,Y,PC
01389	*			
01390	0938 8D4E	FUNCTR	BSR	READNAME
01391	093A 2607		BNE	FR2
01392	093C 8601		LDA	#READ.
01393	093E 103F84		OS9	I\$OPEN
01394	0941 2536		BCS	ERRFX
01395	0943 8D7A	FR2	BSR	SEEKOFFS
01396	0945 103F89		OS9	I\$READ
01397	0948 252F		BCS	ERRFX
01398	094A 17FC1F		LBSR	SAYDUN
01399	094D 16F8AF		LBRA	MENUX
01400	*			
01401	0950 8D36	FUNCTW	BSR	READNAME
01402	0952 2618		BNE	FW2
01403	0954 3410		PSHS	X
01404	0956 8603		LDA	#UPDAT.
01405	0958 103F84		OS9	I\$OPEN
01406	095B 3510		PULS	X
01407	095D 240D		BCC	FW2
01408	095F C1D8		CMPB	#E\$PNNF
01409	0961 2616		BNE	ERRFX
01410	0963 8603		LDA	#UPDAT.
01411	0965 C60B		LDB	#PREAD.+UPDAT.
01412	0967 103F83		OS9	I\$CREA
01413	096A 250D		BCS	ERRFX
01414	096C 8D51	FW2	BSR	SEEKOFFS
01415	096E 103F8A		OS9	I\$WRIT
01416	0971 2506		BCS	ERRFX
01417	0973 17FBF6		LBSR	SAYDUN
01418	0976 16F886		LBRA	MENUX
01419	*			
01420	0979 8602	ERRFX	LDA	#2
01421	097B 103F0F		OS9	F\$PERR
01422	097E 1025F938		LBCS	YSERR
01423	0982 17FBEE		LBSR	ENDEX
01424	0985 16F877		LBRA	MENUX
01425	*			
01426	0988 308D00A2	READNAME	LEAX	FNAMEQ,PCR
01427	098C 17FF5C		LBSR	PDATA2
01428	098F 30C90186		LEAX	NBUFF,U
01429	0993 108E0050		LDY	#NBUFFL
01430	0997 8602		LDA	#2
01431	0999 103F8B		OS9	I\$RDLN
01432	099C 1025F91A		LBCS	YSERR
01433	09A0 108C0001		CMPLY	#1
01434	09A4 2606		BNE	RN1
01435	09A6 A684		LDA	,X
01436	09A8 810D		CMPLA	##0D
01437	09AA 270E		BEQ	RN9
01438	09AC 9627	RN1	LDA	FILE
01439	09AE 2709		BEQ	RN2
01440	09B0 103F8F		OS9	I\$CLOS
01441	09B3 1025F903		LBCS	YSERR

01442	09B7	0F27		CLR	FILE
01443	09B9	39	RN2	RTS	
01444		*			
01445	09BA	9627	RN9	LDA	FILE
01446	09BC	27CA		BEQ	READNAME
01447	09BE	39		RTS	
01448		*			
01449	09BF	9727	SEEKOFFS	STA	FILE
01450	09C1	3410		PSHS	X
01451	09C3	308D0080	SK1	LEAX	FOFFS,PCR
01452	09C7	17FF21		LBSR	PDATA2
01453	09CA	17FE81		LBSR	BADDR
01454	09CD	0D1D		TST	ERFLG
01455	09CF	26F2		BNE	SK1
01456	09D1	9627		LDA	FILE
01457	09D3	3440		PSHS	U
01458	09D5	1F13		TFR	X,U
01459	09D7	8E0000		LDX	#0
01460	09DA	103F88		OS9	I\$SEEK
01461	09DD	3540		PULS	U
01462	09DF	1025F8D7		LBCS	SYSERR
01463	09E3	3402		PSHS	A
01464	09E5	9E0A		LDX	LIMIT
01465	09E7	3410		PSHS	X
01466	09E9	8E4000		LDX	#BUFFHI
01467	09EC	9F0A		STX	LIMIT
01468	09EE	308D006D	SK3	LEAX	BOFFS,PCR
01469	09F2	17FEF6		LBSR	PDATA2
01470	09F5	17FE56		LBSR	BADDR
01471	09F8	0D1D		TST	ERFLG
01472	09FA	26F2		BNE	SK3
01473	09FC	17FED1		LBSR	LIMCHK
01474	09FF	25ED		BCS	SK3
01475	0A01	1F10		TFR	X,D
01476	0A03	3406		PSHS	D
01477	0A05	30C901D6		LEAX	BUFFER,U
01478	0A09	308B		LEAX	D,X
01479	0A0B	AF65		STX	S,S
01480	0A0D	308D0066	SK5	LEAX	BSIZS,PCR
01481	0A11	17FED7		LBSR	PDATA2
01482	0A14	17FE37		LBSR	BADDR
01483	0A17	0D1D		TST	ERFLG
01484	0A19	26F2		BNE	SK5
01485	0A1B	1F12		TFR	X,Y
01486	0A1D	3506		PULS	D
01487	0A1F	308B		LEAX	D,X
01488	0A21	301F		LEAX	-1,X
01489	0A23	17FEAA		LBSR	LIMCHK
01490	0A26	25C6		BCS	SK3
01491	0A28	3510		PULS	X
01492	0A2A	9F0A		STX	LIMIT
01493	0A2C	3592		PULS	A,X,PC
01494		*			
01495		*			
01496		*****			
01497		*			
01498		*			
01499	0A2E	0D0A0A	FNAMEQ	FCB	\$0D,\$0A,\$0A
01500	0A31	454E5445		FCC	'ENTER NAME OF FILE :'
01501	0A46	04		FCB	\$04

```

01502      *
01503      0A47 0D0A      FOFFS      FCB      $0D,$0A
01504      0A49 454E5445      FCC      'ENTER FILE OFFSET $'
01505      0A5E 04      FCB      $04
01506      *
01507      0A5F 0D0A      BOFFS      FCB      $0D,$0A
01508      0A61 454E5445      FCC      'ENTER BUFFER OFFSET $'
01509      0A76 04      FCB      $04
01510      *
01511      0A77 0D0A      BSIZS      FCB      $0D,$0A
01512      0A79 454E5445      FCC      'ENTER TRANSFER SIZE $'
01513      0A8E 04      FCB      $04
01514      *
01515      *
01516      *****
01517      *
01518      *
01519      0A8F 0D0A      MORMSG      FCB      $0D,$0A
01520      0A91 4D4F5245      FCC      'MORE? (Y/N) '
01521      0A9E 04      FCB      $04
01522      *
01523      0A9F 0D0A0A07      MERMSG      FCB      $0D,$0A,$0A,$07
01524      0AA3 3C2A3E20      FCC      '<*> BUFFER LIMITS EXCEEDED! CHECK ADDRES
01525      0AD3 0A0A0D04      FCB      $0A,$0A,$0D,$04
01526      *
01527      0AD7 0D0A      MSG1      FCB      $0D,$0A
01528      0AD9 454E5445      FCC      'ENTER START ADDRESS $'
01529      0AEE 04      FCB      $04
01530      *
01531      0AEF 0D0A      MSG2      FCB      $0D,$0A
01532      0AF1 454E5445      FCC      'ENTER END ADDRESS $'
01533      0B06 04      FCB      $04
01534      *
01535      0B07 0A0A0D07      MSG3      FCB      $0A,$0A,$0D,$07
01536      0B0B 3C2A3E20      FCC      '<*> THE ADDRESS INPUT IS OUT OF RANGE! R
01537      0B3F 0D0A04      FCB      $0D,$0A,$04
01538      *
01539      0B42 0A0D04      CRLF1      FCB      $0A,$0D,$04
01540      *
01541      0B45 0D0A0A07      MSG4      FCB      $0D,$0A,$0A,$07
01542      0B49 3C2A3E20      FCC      '<*> PROM NOT ERASED AT ADDRESS $'
01543      0B6A 04      FCB      $04
01544      *
01545      0B6B 0D0A0A07      MSG5      FCB      $0D,$0A,$0A,$07
01546      0B6F 3C2A3E20      FCC      '<*> VERIFY FAILED AT ADDRESS $'
01547      0B90 04      FCB      $04
01548      *
01549      0B91 0D0A      MSG6      FCB      $0D,$0A
01550      0B93 50524F47      FCC      'PROGRAM ANYWAY? (Y/N) '
01551      0BAC 04      FCB      $04
01552      *
01553      0BAD 0D0A0A      MSG8      FCB      $0D,$0A,$0A
01554      0BB0 45524153      FCC      'ERASE CHECK O.K.'
01555      0BC2 0D0A      MSG8A      FCB      $0D,$0A
01556      0BC4 53544152      FCC      'START PROGRAMMING? (Y/N) '
01557      0BDD 04      FCB      $04
01558      *
01559      0BDE 0D0A0A      MSG9      FCB      $0D,$0A,$0A
01560      0BE1 2A2A2A2A      FCC      '*****
01561      0C09 0A0D      FCB      $0A,$0D

```

```

01562 0C0B 2A205052 FCC '* PROGRAMMING & VERIFICATION COMPLETED *
01563 0C33 0A0D FCB $0A,$0D
01564 0C35 2A2A2A2A FCC '*****
01565 0C5D 0A0A0D07 FCB $0A,$0A,$0D,$07,$04
01566 *
01567 0C62 0A0A0D DMPMSG FCB $0A,$0A,$0D
01568 0C65 2A2A2A2A FCC '*****'
01569 0C77 0A0D FCB $0A,$0D
01570 0C79 2A20464F FCC '* FORMATTED DUMP *'
01571 0C8B 0A0D FCB $0A,$0D
01572 0C8D 2A2A2A2A FCC '*****'
01573 0C9F 0D0A0A FCB $0D,$0A,$0A
01574 0CA2 454E5445 FCC 'ENTER START ADDRESS $'
01575 0CB7 04 FCB $04
01576 *
01577 0CB8 0D0A0A FILMES FCB $0D,$0A,$0A
01578 0CBB 2A2A2A2A FCC '*****'
01579 0CCA 0A0D FCB $0A,$0D
01580 0CCC 2A204649 FCC '* FILL BUFFER *'
01581 0CDB 0A0D FCB $0A,$0D
01582 0CDD 2A2A2A2A FCC '*****'
01583 0CEC 0D0A0A FCB $0D,$0A,$0A
01584 0CEF 454E5445 FCC 'ENTER HEX FILL BYTE $'
01585 0D04 04 FCB $04
01586 *
01587 0D05 0A0A0D INSMMSG FCB $0A,$0A,$0D
01588 0D08 2A2A2A2A FCC '*****'
01589 0D23 0A0D FCB $0A,$0D
01590 0D25 2A204558 FCC '* EXAMINE & CHANGE BUFFER *'
01591 0D40 0A0D FCB $0A,$0D
01592 0D42 2A2A2A2A FCC '*****'
01593 0D5D 0A0D0A FCB $0A,$0D,$0A
01594 0D60 22535041 FCC '"SPACE" TO STEP, "U" OR "^" FOR PREV'
01595 0D84 0A0D FCB $0A,$0D
01596 0D86 22432F52 FCC '"C/R" TO RETURN TO MAIN MENU.'
01597 0DA3 0A0A0D FCB $0A,$0A,$0D
01598 0DA6 53544152 FCC 'STARTING ADDRESS $'
01599 0DB8 04 FCB $04
01600 *
01601 0DB9 20203C2A NOHEXM FCC ' <*> NOT A HEX NUMBER <*>'
01602 0DD3 070D0A04 FCB $07,$0D,$0A,$04
01603 *
01604 0DD7 0D0A0A MSG12 FCB $0D,$0A,$0A
01605 0DDA 52454144 FCC 'READY TO CONTINUE? (Y/N) '
01606 0DF4 04 FCB $04
01607 *
01608 0DF5 0D0A0A0A BANNER FCB $0D,$0A,$0A,$0A,$0A,$0A,$0A,$0A
01609 0DFD 20202020 FCC ' WINDRUSH MICRO SYSTEMS'
01610 0E1F 0A0A0D FCB $0A,$0A,$0D
01611 0E22 20202020 FCC ' UNIVERSAL EPROM PROGRAMMER VERSION 2
01612 0E4D 0A0A0A0D FCB $0A,$0A,$0A,$0D
01613 0E51 202A2A2A FCC ' *****
01614 0E7E 0D0A FCB $0D,$0A
01615 0E80 202A2020 FCC ' * DO NOT INSERT EPROM UNTIL PROMPTED
01616 0EAD 0D0A FCB $0D,$0A
01617 0EAF 202A2A2A FCC ' *****
01618 0EDC 0D0A04 FCB $0D,$0A,$04
01619 *
01620 0EDF 0D0A0A BADDP FCB $0D,$0A,$0A
01621 0EE2 454E5445 FCC 'ENTER EPROM PROGRAMMER PIA BASE ADDRESS
  
```

01622	0F0E	04		FCB	\$04
01623		*			
01624	0F0F	0A0A0D	MENU	FCB	\$0A,\$0A,\$0D
01625	0F12	2020202A		FCC	'*****'
01626	0F24	0A0D		FCB	\$0A,\$0D
01627	0F26	2020202A		FCC	'* EPROM TYPES *'
01628	0F38	0A0D		FCB	\$0A,\$0D
01629	0F3A	2020202A		FCC	'*****'
01630	0F4C	0A0A0D		FCB	\$0A,\$0A,\$0D
01631	0F4F	32353038		FCC	'2508 (5.0 VOLT) = 0'
01632	0F65	0A0D		FCB	\$0A,\$0D
01633	0F67	32373038		FCC	'2708 (TRI VOLT) = 1'
01634	0F7D	0A0D		FCB	\$0A,\$0D
01635	0F7F	32353136		FCC	'2516 (5.0 VOLT) = 2'
01636	0F95	0A0D		FCB	\$0A,\$0D
01637	0F97	32373136		FCC	'2716 (TRI VOLT) = 3'
01638	0FAD	0A0D		FCB	\$0A,\$0D
01639	0FAF	32353332		FCC	'2532 (5.0 VOLT) = 4'
01640	0FC5	0A0D		FCB	\$0A,\$0D
01641	0FC7	32373332		FCC	'2732 (5.0 VOLT) = 5'
01642	0FDD	0A0D		FCB	\$0A,\$0D
01643	0FDF	32373332		FCC	'2732A (5.0 VOLT) = 6'
01644	0FF5	0A0D		FCB	\$0A,\$0D
01645	0FF7	32353634		FCC	'2564 (5.0 VOLT) = 7'
01646	100D	0A0D		FCB	\$0A,\$0D
01647	100F	32373634		FCC	'2764 (5.0 VOLT) = 8'
01648	1025	0A0D		FCB	\$0A,\$0D
01649	1027	32353238		FCC	'2528 (5.0 VOLT) = 9'
01650	103D	0A0A0D		FCB	\$0A,\$0A,\$0D
01651	1040	53454C45		FCC	'SELECT TYPE BY NUMBER:-'
01652	1057	04		FCB	\$04
01653		*			
01654	1058	0A0D	SWPRMT	FCB	\$0A,\$0D
01655	105A	2A2A2A2A		FCC	'*****'
01656	107D	0A0D		FCB	\$0A,\$0D
01657	107F	2A20414C		FCC	'* ALL SWITCHES ON THE OTHER EPROM *'
01658	10A2	0A0D		FCB	\$0A,\$0D
01659	10A4	2A20534F		FCC	'* SOCKET MUST BE SET TO THE RIGHT *'
01660	10C7	0A0D		FCB	\$0A,\$0D
01661	10C9	2A2A2A2A		FCC	'*****'
01662	10EC	0D0A0A	SWPMT	FCB	\$0D,\$0A,\$0A
01663	10EF	454E5355		FCC	'ENSURE SWITCHES ARE SET AS INSTRUCTED!'
01664	1115	0D0A0A		FCB	\$0D,\$0A,\$0A
01665	1118	2A2A2A2A	PLEPRM	FCC	'*****'
01666	1131	0A0D		FCB	\$0A,\$0D
01667	1133	2A20504C		FCC	'* PLACE EPROM IN SOCKET *'
01668	114C	0A0D		FCB	\$0A,\$0D
01669	114E	2A2A2A2A		FCC	'*****'
01670	1167	0D0A04		FCB	\$0D,\$0A,\$04
01671		*			
01672	116A	0D0A0A0A	INMSG0	FCB	\$0D,\$0A,\$0A,\$0A
01673	116E	2A2A2A2A		FCC	'*****'
01674	1176	0D0A		FCB	\$0D,\$0A
01675	1178	2A203235		FCC	'* 2508 *'
01676	1180	0D0A		FCB	\$0D,\$0A
01677	1182	2A2A2A2A		FCC	'*****'
01678	118A	0D0A0A		FCB	\$0D,\$0A,\$0A
01679	118D	53455420		FCC	'SET SWA = 1,3,6,9,10 LEFT, ALL OTHERS RI
01680	11B9	0D0A04		FCB	\$0D,\$0A,\$04
01681	11BC	0D0A0A0A	INMSG1	FCB	\$0D,\$0A,\$0A,\$0A

01682	11C0	2A2A2A2A	FCC	'*****'
01683	11C8	0D0A	FCB	\$0D,\$0A
01684	11CA	2A203237	FCC	'* 2708 *'
01685	11D2	0D0A	FCB	\$0D,\$0A
01686	11D4	2A2A2A2A	FCC	'*****'
01687	11DC	0D0A0A	FCB	\$0D,\$0A,\$0A
01688	11DF	53455420	FCC	'SET SWA = 10 LEFT, ALL OTHERS RIGHT.'
01689	1203	0D0A04	FCB	\$0D,\$0A,\$04
01690	*			
01691	1206	0D0A0A0A	INMSG2 FCB	\$0D,\$0A,\$0A,\$0A
01692	120A	2A2A2A2A	FCC	'*****'
01693	1212	0D0A	FCB	\$0D,\$0A
01694	1214	2A203235	FCC	'* 2516 *'
01695	121C	0D0A	FCB	\$0D,\$0A
01696	121E	2A2A2A2A	FCC	'*****'
01697	1226	0D0A0A	FCB	\$0D,\$0A,\$0A
01698	1229	53455420	FCC	'SET SWA = 1,3,6,9,10 LEFT, ALL OTHERS RI
01699	1255	0D0A04	FCB	\$0D,\$0A,\$04
01700	*			
01701	1258	0D0A0A0A	INMSG3 FCB	\$0D,\$0A,\$0A,\$0A
01702	125C	2A2A2A2A	FCC	'*****'
01703	1264	0D0A	FCB	\$0D,\$0A
01704	1266	2A203237	FCC	'* 2716 *'
01705	126E	0D0A	FCB	\$0D,\$0A
01706	1270	2A2A2A2A	FCC	'*****'
01707	1278	0D0A0A	FCB	\$0D,\$0A,\$0A
01708	127B	53455420	FCC	'SET SWA = 10 LEFT, ALL OTHERS RIGHT.'
01709	129F	0D0A	FCB	\$0D,\$0A
01710	12A1	53455420	FCC	'SET SWB = 8,9 LEFT, ALL OTHERS RIGHT.'
01711	12C6	0D0A04	FCB	\$0D,\$0A,\$04
01712	*			
01713	12C9	0D0A0A0A	INMSG4 FCB	\$0D,\$0A,\$0A,\$0A
01714	12CD	2A2A2A2A	FCC	'*****'
01715	12D5	0D0A	FCB	\$0D,\$0A
01716	12D7	2A203235	FCC	'* 2532 *'
01717	12DF	0D0A	FCB	\$0D,\$0A
01718	12E1	2A2A2A2A	FCC	'*****'
01719	12E9	0D0A0A	FCB	\$0D,\$0A,\$0A
01720	12EC	53455420	FCC	'SET SWA = 1,4,7,9,10 LEFT, ALL OTHERS RI
01721	1318	0D0A04	FCB	\$0D,\$0A,\$04
01722	*			
01723	131B	0D0A0A0A	INMSG5 FCB	\$0D,\$0A,\$0A,\$0A
01724	131F	2A2A2A2A	FCC	'*****'
01725	1327	0D0A	FCB	\$0D,\$0A
01726	1329	2A203237	FCC	'* 2732 *'
01727	1331	0D0A	FCB	\$0D,\$0A
01728	1333	2A2A2A2A	FCC	'*****'
01729	133B	0D0A0A	FCB	\$0D,\$0A,\$0A
01730	133E	53455420	FCC	'SET SWA = ALL SWITCHES LEFT.'
01731	135A	0D0A04	FCB	\$0D,\$0A,\$04
01732	*			
01733	135D	0D0A0A0A	INMSG6 FCB	\$0D,\$0A,\$0A,\$0A
01734	1361	2A2A2A2A	FCC	'*****'
01735	136A	0D0A	FCB	\$0D,\$0A
01736	136C	2A203237	FCC	'* 2732A *'
01737	1375	0D0A	FCB	\$0D,\$0A
01738	1377	2A2A2A2A	FCC	'*****'
01739	1380	0D0A0A	FCB	\$0D,\$0A,\$0A
01740	1383	53455420	FCC	'SET SWA = 10 RIGHT, ALL OTHERS LEFT.'
01741	13A7	0D0A04	FCB	\$0D,\$0A,\$04


```

01742      *
01743      13AA 0D0A0A0A      INMSG7      FCB      $0D,$0A,$0A,$0A
01744      13AE 2A2A2A2A      FCC      '*****'
01745      13B6 0D0A      FCB      $0D,$0A
01746      13B8 2A203235      FCC      '* 2564 *'
01747      13C0 0D0A      FCB      $0D,$0A
01748      13C2 2A2A2A2A      FCC      '*****'
01749      13CA 0D0A0A      FCB      $0D,$0A,$0A
01750      13CD 53455420      FCC      'SET SWB = 10 LEFT, ALL OTHERS RIGHT.'
01751      13F1 0D0A04      FCB      $0D,$0A,$04
01752      *
01753      13F4 0D0A0A0A      INMSG8      FCB      $0D,$0A,$0A,$0A
01754      13F8 2A2A2A2A      FCC      '*****'
01755      1400 0D0A      FCB      $0D,$0A
01756      1402 2A203237      FCC      '* 2764 *'
01757      140A 0D0A      FCB      $0D,$0A
01758      140C 2A2A2A2A      FCC      '*****'
01759      1414 0D0A0A      FCB      $0D,$0A,$0A
01760      1417 53455420      FCC      'SET SWB = 8,9,10 RIGHT, ALL OTHERS LEFT.'
01761      143F 0D0A04      FCB      $0D,$0A,$04
01762      *
01763      1442 0D0A0A0A      INMSG9      FCB      $0D,$0A,$0A,$0A
01764      1446 2A2A2A2A      FCC      '*****'
01765      144E 0D0A      FCB      $0D,$0A
01766      1450 2A203235      FCC      '* 2528 *'
01767      1458 0D0A      FCB      $0D,$0A
01768      145A 2A2A2A2A      FCC      '*****'
01769      1462 0D0A0A      FCB      $0D,$0A,$0A
01770      1465 53455420      FCC      'SET SWB = 2,3,10 LEFT, ALL OTHERS RIGHT.'
01771      148D 0D0A04      FCB      $0D,$0A,$04
01772      *
01773      1490 0D0A0A      FRAME      FCB      $0D,$0A,$0A
01774      1493 20202020      FCC      '*****'
01775      14AF 0A0D      FCB      $0A,$0D
01776      14B1 20202020      FCC      '* '
01777      14BA 04      FCB      $04
01778      *
01779      14BB 202A      FMENU      FCC      '* '
01780      14BD 0A0D      FCB      $0A,$0D
01781      14BF 20202020      FCC      '*****'
01782      14DB 0D0A      FCB      $0D,$0A
01783      14DD 20202020      FCC      '* OPERATIONS MENU *'
01784      14F9 0D0A      FCB      $0D,$0A
01785      14FB 20202020      FCC      '*****'
01786      1517 0A0A0D      FCB      $0A,$0A,$0D
01787      151A 46494C4C      FCC      'FILL BUFFER AREA WITH A HEX CHAR = 0'
01788      153E 0A0D      FCB      $0A,$0D
01789      1540 4D4F5645      FCC      'MOVE DATA WITHIN THE BUFFER = 1'
01790      1564 0A0D      FCB      $0A,$0D
01791      1566 434F5059      FCC      'COPY A PROM TO THE BUFFER = 2'
01792      158A 0A0D      FCB      $0A,$0D
01793      158C 56455249      FCC      'VERIFY A PROM AGAINST THE BUFFER = 3'
01794      15B0 0A0D      FCB      $0A,$0D
01795      15B2 50524F47      FCC      'PROGRAM A PROM FROM THE BUFFER = 4'
01796      15D6 0A0D      FCB      $0A,$0D
01797      15D8 4558414D      FCC      'EXAMINE OR CHANGE THE BUFFER = 5'
01798      15FC 0A0D      FCB      $0A,$0D
01799      15FE 464F524D      FCC      'FORMATTED DUMP OF THE BUFFER = 6'
01800      1622 0A0D      FCB      $0A,$0D
01801      1624 52455455      FCC      'RETURN TO EPROM SELECT MENU = 7'

```

01802	1648	0A0D		FCB	\$0A,\$0D
01803	164A	52455455		FCC	'RETURN TO DISK OPERATING SYSTEM = 9'
01804	166E	0D0A		FCB	\$0D,\$0A
01805	1670	52454144		FCC	'READ BUFFER AREA FROM DISC FILE = R'
01806	1694	0D0A		FCB	\$0D,\$0A
01807	1696	57524954		FCC	'WRITE BUFFER AREA TO DISC FILE = W'
01808	16BA	0D0A0A		FCB	\$0D,\$0A,\$0A
01809	16BD	53454C45		FCC	'SELECT OPERATION BY NUMBER OR LETTER :-'
01810	16E4	04		FCB	\$04
01811		*			
01812	16E5	32353038	H2508	FCC	'2508 \$0000-\$03FF'
01813	16F6	04		FCB	\$04
01814	16F7	32373038	H2708	FCC	'2708 \$0000-\$03FF'
01815	1708	04		FCB	\$04
01816	1709	32353136	H2516	FCC	'2516 \$0000-\$07FF'
01817	171A	04		FCB	\$04
01818	171B	32373136	H2716	FCC	'2716 \$0000-\$07FF'
01819	172C	04		FCB	\$04
01820	172D	32353332	H2532	FCC	'2532 \$0000-\$0FFF'
01821	173E	04		FCB	\$04
01822	173F	32373332	H2732	FCC	'2732 \$0000-\$0FFF'
01823	1750	04		FCB	\$04
01824	1751	32373332	H2732A	FCC	'2732A \$0000-\$0FFF'
01825	1762	04		FCB	\$04
01826	1763	32353634	H2564	FCC	'2564 \$0000-\$1FFF'
01827	1774	04		FCB	\$04
01828	1775	32373634	H2764	FCC	'2764 \$0000-\$1FFF'
01829	1786	04		FCB	\$04
01830	1787	32353238	H2528	FCC	'2528 \$0000-\$3FFF'
01831	1798	04		FCB	\$04
01832		*			
01833	1799	0A0A0D	CPYMSG	FCB	\$0A,\$0A,\$0D
01834	179C	2A2A2A2A		FCC	'*****'
01835	17AA	0A0D		FCB	\$0A,\$0D
01836	17AC	2A20434F		FCC	'* COPY EPROM *'
01837	17BA	0A0D		FCB	\$0A,\$0D
01838	17BC	2A2A2A2A		FCC	'*****'
01839	17CA	0A0D04		FCB	\$0A,\$0D,\$04
01840		*			
01841	17CD	0A0A0D	VERMSG	FCB	\$0A,\$0A,\$0D
01842	17D0	2A2A2A2A		FCC	'*****'
01843	17E0	0A0D		FCB	\$0A,\$0D
01844	17E2	2A205645		FCC	'* VERIFY EPROM *'
01845	17F2	0A0D		FCB	\$0A,\$0D
01846	17F4	2A2A2A2A		FCC	'*****'
01847	1804	0A0D04		FCB	\$0A,\$0D,\$04
01848		*			
01849	1807	0D0A0A	PFRAME	FCB	\$0D,\$0A,\$0A
01850	180A	2A2A2A2A		FCC	'*****'
01851	181B	0D0A		FCB	\$0D,\$0A
01852	181D	04		FCB	\$04
01853		*			
01854	181E	0D0A	PRGMSG	FCB	\$0D,\$0A
01855	1820	2A2A2A2A		FCC	'*****'
01856	1831	0A0D		FCB	\$0A,\$0D
01857	1833	2A205052		FCC	'* PROGRAM EPROM *'
01858	1844	0A0D		FCB	\$0A,\$0D
01859	1846	2A2A2A2A		FCC	'*****'
01860	1857	0A0D04		FCB	\$0A,\$0D,\$04
01861		*			

```

01862 185A 0D0A0A      DUNMSG  FCB  $0D,$0A,$0A
01863 185D 2A2A2A2A    FCC  '*****'
01864 1873 0A0D        FCB  $0A,$0D
01865 1875 2A204655    FCC  '* FUNCTION COMPLETED *'
01866 188B 0A0D        FCB  $0A,$0D
01867 188D 2A2A2A2A    FCC  '*****'
01868 18A3 0A0D0704    FCB  $0A,$0D,$07,$04
01869      *
01870 18A7 0A0A0D      MVMSG1  FCB  $0A,$0A,$0D
01871 18AA 2A2A2A2A    FCC  '*****'
01872 18B7 0D0A        FCB  $0D,$0A
01873 18B9 2A204D4F    FCC  '* MOVE DATA *'
01874 18C6 0D0A        FCB  $0D,$0A
01875 18C8 2A2A2A2A    FCC  '*****'
01876 18D5 0D0A0A      FCB  $0D,$0A,$0A
01877 18D8 46524F4D    FCC  'FROM      ADDRESS? #'
01878 18EA 04          FCB  $04
01879      *
01880 18EB 0D0A          MVMSG2  FCB  $0D,$0A
01881 18ED 544F2020    FCC  'TO      ADDRESS? #'
01882 18FF 04          FCB  $04
01883      *
01884 1900 0D0A          SZMSG1  FCB  $0D,$0A
01885 1902 4E554D42    FCC  'NUMBER OF BYTES? #'
01886 1914 04          FCB  $04
01887      *
01888 1915 0D0A0A      CONMSG  FCB  $0D,$0A,$0A
01889 1918 48495420    FCC  'HIT ANY KEY TO CONTINUE'
01890 192F 0D0A04      FCB  $0D,$0A,$04
01891      *
01892 1932 0D0A0A      MSG08   FCB  $0D,$0A,$0A
01893 1935 4E4F2041    FCC  'NO ADDRESS RANGE OPTIONS'
01894 194D 0D0A04      FCB  $0D,$0A,$04
01895      *
01896 1950 0D0A0A0A    MSGPGM  FCB  $0D,$0A,$0A,$0A
01897 1954 2A2A2A2A    FCC  '*****'
01898 196F 0A0D        FCB  $0A,$0D
01899 1971 2A205052    FCC  '* PROGRAMMING IN PROGRESS *'
01900 198C 0A0D        FCB  $0A,$0D
01901 198E 2A2A2A2A    FCC  '*****'
01902 19A9 0D0A04      FCB  $0D,$0A,$04
01903      *
01904      *
01905 19AC E7E52D      EMOD
01906      *
01907 19AF      MODEND  EQU  *
01908      *
01909      END
  
```

```

00000 error(s)
00005 warning(s)
$19AF 06575 program bytes generated
$41D6 16854 data bytes allocated
$2389 09097 bytes used for symbols
  
```